



European Facility  
for Airborne Research

# **EGADS Lineage Documentation**

*Release 1.0.1*

**EU FAR, Olivier Henry**

**Aug 12, 2019**

# CONTENTS

<b>1</b>	<b>Introduction</b>	<b>1</b>
<b>2</b>	<b>Installation</b>	<b>2</b>
2.1	Prerequisites . . . . .	2
2.2	Installation . . . . .	2
2.3	Testing . . . . .	2
2.4	Options . . . . .	2
2.5	Log . . . . .	3
2.6	Update . . . . .	3
<b>3</b>	<b>Tutorial</b>	<b>5</b>
3.1	Exploring EGADS . . . . .	5
3.1.1	Simple operations with EGADS . . . . .	5
3.2	The EgadsData class . . . . .	6
3.2.1	Creating EgadsData instances . . . . .	6
3.2.2	Metadata . . . . .	6
3.2.3	Working with units . . . . .	7
3.3	Working with raw text files . . . . .	8
3.3.1	Opening . . . . .	8
3.3.2	File Manipulation . . . . .	8
3.3.3	Reading Data . . . . .	8
3.3.4	Writing Data . . . . .	9
3.3.5	Closing . . . . .	9
3.3.6	Tutorial . . . . .	9
3.4	Working with CSV files . . . . .	11
3.4.1	Opening . . . . .	11
3.4.2	File Manipulation . . . . .	11
3.4.3	Reading Data . . . . .	12
3.4.4	Writing Data . . . . .	12
3.4.5	Closing . . . . .	12
3.4.6	Tutorial . . . . .	13
3.5	Working with NetCDF files . . . . .	14
3.5.1	Opening . . . . .	14
3.5.2	Getting info . . . . .	14
3.5.3	Reading data . . . . .	15
3.5.4	Writing data . . . . .	15
3.5.5	Conversion from NetCDF to NASA Ames file format . . . . .	16
3.5.6	Other operations . . . . .	16
3.5.7	Closing . . . . .	17
3.5.8	Tutorial . . . . .	17
3.6	Working with NASA Ames files . . . . .	19
3.6.1	Opening . . . . .	19
3.6.2	Getting info . . . . .	19
3.6.3	Reading data . . . . .	20

3.6.4	Writing data . . . . .	20
3.6.5	Saving a file . . . . .	21
3.6.6	Conversion from NASA/Ames file format to NetCDF . . . . .	22
3.6.7	Other operations . . . . .	22
3.6.8	Closing . . . . .	22
3.6.9	Tutorial . . . . .	22
3.7	Working with algorithms . . . . .	25
3.7.1	Getting algorithm information . . . . .	25
3.7.2	Calling algorithms . . . . .	25
3.8	Scripting . . . . .	27
3.8.1	Scripting Hints . . . . .	27
3.9	Using the GUI . . . . .	28
<b>4</b>	<b>Algorithm Development</b>	<b>29</b>
4.1	Introduction . . . . .	29
4.2	Python module creation . . . . .	29
4.3	Documentation creation . . . . .	33
4.3.1	Example . . . . .	33
<b>5</b>	<b>EGADS API</b>	<b>35</b>
5.1	Core Classes . . . . .	35
5.2	Metadata Classes . . . . .	36
5.3	File Classes . . . . .	38
	<b>Python Module Index</b>	<b>49</b>

## INTRODUCTION

The EGADS (EUFAR General Airborne Data-processing Software) core is a Python-based library of processing and file I/O routines designed to help analyze a wide range of airborne atmospheric science data. EGADS purpose is to provide a benchmark for airborne data-processing through its community-provided algorithms, and to act as a reference by providing guidance to researchers with an open-source design and well-documented processing routines.

Python is used in development of EGADS due to its straightforward syntax and portability between systems. Users interact with data processing algorithms using the Python command-line, by creating Python scripts for more complex tasks, or by using the EGADS GUI for a simplified interaction. The core of EGADS is built upon a data structure that encapsulates data and metadata into a single object. This simplifies the housekeeping of data and metadata and allows these data to be easily passed between algorithms and data files. Algorithms in EGADS also contain metadata elements that allow data and their sources to be tracked through processing chains.

As the EUFAR FP7 project ended the 31st of January 2018, the development of EGADS has been stopped for now. To continue to improve EGADS outside the scope of EUFAR, a new branch has been created: EGADS Lineage. EGADS Lineage is still EGADS, but compatible with Python 3 and maintained by Olivier Henry. All issues reported in EGADS and EGADS Lineage will be fixed in EGADS Lineage only. A merging of both project will probably happen in the next EUFAR project.

---

**Note:** Even if EGADS is easily accessible, a certain knowledge in Python is still required to use EGADS.

---

## INSTALLATION

The latest version of EGADS Lineage can be obtained from GitHub (<https://github.com/EUFAR/egads/tree/Lineage>) or from PyPi (<https://pypi.org/project/egads-lineage/>)

### 2.1 Prerequisites

Use of EGADS requires the following packages:

- Python 3.5.4 or newer. Available at <https://www.python.org/>
- numpy 1.14 or newer. Available at <http://numpy.scipy.org/>
- scipy 1.00 or newer. Available at <http://www.scipy.org/>
- Python netCDF4 libraries 1.3.0 or newer. Available at <https://pypi.python.org/pypi/netCDF4>
- python\_dateutil 2.6.1 or newer. Available at <https://pypi.python.org/pypi/python-dateutil>
- quantities 0.12.1 or newer. Available at <https://pypi.org/project/quantities>
- requests 2.18.4 or newer. Optional, only for update checking. Available at <https://pypi.org/project/requests/>

### 2.2 Installation

Since EGADS is a pure Python distribution, it does not need to be built. However, to use it, it must be installed to a location on the Python path. To install EGADS, first download and decompress the file. From the directory containing the file `setup.py`, type `python setup.py install` or `pip install egads-lineage` from the command line. To install to a user-specified location, type `python setup.py install --prefix=$MYDIR`. To avoid the installation of dependencies, use the option `--no-depts`. On Linux systems, the installation of EGADS in the user home directory is encouraged to ensure the proper operation of the EGADS logging system and of the new Graphical User Interface algorithm creation system.

### 2.3 Testing

To test EGADS after it is installed, from Python terminal, run the following commands:

```
>>> import egads
>>> egads.test()
```

### 2.4 Options

Since version 0.7.0, an `.ini` file has been added to EGADS to welcome few options: log level and path, automatic check for a new EGADS version on GitHub. If the file is not present in EGADS directory, when importing, EGADS will create it automatically with default options. It is possible to display the status of the configuration file:

```
>>> import egads
>>> egads.print_options()
EGADS options:
- logging level: DEBUG
- log path: PATH_TO_PYTHON\Python35\lib\site-packages\egads
- update automatic check: False
```

Actually, the number of option is limited and will probably increase in the future. Here is a list of all options:

- level in LOG section: one of the items in the following list DEBUG, INFO, WARNING, CRITICAL, ERROR ; it is used to set the logging level when EGADS is imported.
- path in LOG section: a string corresponding to an OS path ; it is used to set the directory path where the log file is saved.
- check\_update in OPTIONS section: True or False ; it is used to let EGADS check for an update automatically when it is imported.

## 2.5 Log

A logging system has been introduced in EGADS since the version 0.7.0. By default, the output file is available in the 'Python local site-packages/egads' directory and the logging level has been set to INFO. Both options for logging level and logging location have been set in a config file. Both options can be changed through EGADS using the `egads.set_log_options()` function, by passing a dictionary of option keys and values:

```
>>> import egads
>>> egads.set_options(log_level='INFO', log_path='/path/to/log/directory/')
>>> egads.set_options(log_level='INFO')
>>> egads.set_options(log_path='/path/to/log/directory/')
>>> exit()
```

Actual options to control the logging system are for now:

- level: the logging level (DEBUG, INFO, WARNING, CRITICAL, ERROR).
- path: the path of the file containing all logs.

New logging options will be loaded at the next import of EGADS. Logging levels are the standard Python ones (DEBUG, INFO, WARNING, CRITICAL, ERROR). It is also possible to change dynamically the logging level in a script:

```
>>> egads.change_log_level('DEBUG')
```

That possibility is not permanent and will last until the script run is over.

## 2.6 Update

Since version 0.8.6, EGADS can check for an update on GitHub. The check system is launched in a separate thread and can be used this way:

```
>>> import egads
>>> egads.check_update()
EGADS Lineage vx.x.x is available on GitHub. You can update EGADS Lineage by using
↳ pip (pip install egads-lineage --upgrade)
or by using the following link: https://github.com/eufarn7sp/egads/releases/
↳ download/x.x.x/egads-x.x.x.tar.gz
```

If the `check_update` option is set on True in the `egads.ini` file, EGADS will check automatically for an update each time it is imported. By default, the option is set on False. The user can modify the option this way:

```
>>> import egads
>>> egads.set_options(check_update=True)
>>> exit()
```

The use of pip is still required to update EGADS package. The module Requests is optional for EGADS but is mandatory to check for an update.

## 3.1 Exploring EGADS

The simplest way to start working with EGADS is to run it from the Python command line. To load EGADS into the Python name-space, simply import it:

```
>>> import egads
```

You may then begin working with any of the algorithms and functions contained in EGADS.

There are several useful methods to explore the routines contained in EGADS. The first is using the Python built-in `dir()` command:

```
>>> dir(egads)
```

returns all the classes and subpackages contained in EGADS. EGADS follows the naming conventions from the Python Style Guide (<http://www.python.org/dev/peps/pep-0008>), so classes are always `MixedCase`, functions and modules are generally `lowercase` or `lowercase_with_underscores`. As a further example,

```
>>> dir(egads.input)
```

would return all the classes and subpackages of the `egads.input` module.

Another way to explore EGADS is by using tab completion, if supported by your Python installation. Typing

```
>>> egads.
```

then hitting `TAB` will return a list of all available options.

Python has built-in methods to display documentation on any function known as docstrings. The easiest way to access them is using the `help()` function:

```
>>> help(egads.input.NetCdf)
```

or

```
>>> egads.input.NetCdf?
```

will return all methods and their associated documentation for the `NetCdf` class.

### 3.1.1 Simple operations with EGADS

To have a list of file in a directory, use the following function:

```
>>> egads.input.get_file_list('path/to/all/netcdf/files/*.nc')
```



## 3.2 The *EgadsData* class

At the core of the EGADS package is a data class intended to handle data and associated metadata in a consistent way between files, algorithms and within the framework. This ensures that important metadata is not lost when combining data from various sources in EGADS.

Additionally, by subclassing the Quantities and Numpy packages, *EgadsData* incorporates unit comprehension to reduce unit-conversion errors during calculation, and supports broad array manipulation capabilities. This section describes how to employ the *EgadsData* class in the EGADS program scope.

### 3.2.1 Creating *EgadsData* instances

The *EgadsData* class takes four basic arguments:

- **value** Value to assign to *EgadsData* instance. Can be scalar, array, or other *EgadsData* instance.
- **units** Units to assign to *EgadsData* instance. Should be string representation of units, and can be a compound units type such as 'g/kg', 'm/s^2', 'feet/second', etc.
- **variable metadata** An instance of the *VariableMetadata* type or dictionary, containing keywords and values of any metadata to be associated with this *EgadsData* instance.
- **other attributes** Any other attributes added to the class are automatically stored in the *VariableMetadata* instance associated with the *EgadsData* instance.

The following are examples of creating *EgadsData* instances:

```
>>> x = egads.EgadsData([1,2,3], 'm')
>>> a = [1,2,3,4]
>>> b = egads.EgadsData(a, 'km', b_metadata)
>>> c = egads.EgadsData(28, 'degC', long_name="current temperature")
```

If, during the call to *EgadsData*, no units are provided, but a variable metadata instance is provided with a units property, this will then be used to define the *EgadsData* units:

```
>>> x_metadata = egads.core.metadata.VariableMetadata({'units': 'm', 'long_name':
↪ 'Test Variable'})
>>> x = egads.EgadsData([1,2,3], x_metadata)
>>> print x.units
m
>>> print x.metadata
{'units': 'm', 'long_name': 'Test Variable'}
```

The *EgadsData* is a subclass of the Quantities and Numpy packages. Thus it allows different kind of operations like addition, subtraction, slicing, and many more. For each of those operations, a new *EgadsData* class is created with all their attributes.

---

**Note:** With mathematical operands, as metadata define an *EgadsData* before an operation, and may not reflect the new *EgadsData*, it has been decided to not keep the metadata attribute. It's the responsibility of the user to add a new *VariableMetadata* instance or a dictionary to the new *EgadsData* object. It is not true if a user wants to slice an *EgadsData*. In that case, metadata are automatically attributed to the new *EgadsData*.

---

### 3.2.2 Metadata

The metadata object used by *EgadsData* is an instance of *VariableMetadata*, a dictionary object containing methods to recognize, convert and validate known metadata types. It can reference parent metadata objects, such as those from an algorithm or data file, to enable users to track the source of a particular variable.

When reading in data from a supported file type (NetCDF, NASA Ames), or doing calculations with an EGADS algorithm, EGADS will automatically populate the associated metadata and assign it to the output variable. However, when creating an *EgadsData* instance manually, the metadata must be user-defined.

As mentioned, *VariableMetadata* is a dictionary object, thus all metadata are stored as keyword:value pairs. To create metadata manually, simply pass in a dictionary object containing the desired metadata:

```
>>> var_metadata_dict = {'long_name': 'test metadata object',
                        '_FillValue': -9999}
>>> var_metadata = egads.core.metadata.VariableMetadata(var_metadata_dict)
```

To take advantage of its metadata recognition capabilities, a `conventions` keyword can be passed with the variable metadata to give a context to these metadata.

```
>>> var_metadata = egads.core.metadata.VariableMetadata(var_metadata_dict,
↳ conventions='CF-1.0')
```

If a particular *VariableMetadata* object comes from a file or algorithm, the class attempts to assign the conventions automatically. While reading from a file, for example, the class attempts to discover the conventions used based on the “Conventions” keyword, if present.

### 3.2.3 Working with units

*EgadsData* subclasses *Quantities*, thus all of the latter’s unit comprehension methods are available when using *EgadsData*. This section will outline the basics of unit comprehension. A more detailed tutorial of the unit comprehension capabilities can be found at <https://python-quantities.readthedocs.io/en/latest>

In general, units are assigned to *EgadsData* instances when they are being created.

```
>>> a = egads.EgadsData([1,2,3], 'm')
>>> b = egads.EgadsData([4,5,6], 'meters/second')
```

Once a unit type has been assigned to an *EgadsData* instance, it will remain that class of unit and can only be converted between other types of that same unit. The `rescale` method can be used to convert between similar units, but will give an error if an attempt is made to convert to non-compatible units.

```
>>> a = egads.EgadsData([1,2,3], 'm')
>>> a_km = a.rescale('km')
>>> print a_km
['EgadsData', array([0.001, 0.002, 0.003]), 'km']
>>> a_grams = a.rescale('g')
ValueError: Unable to convert between units of "m" and "g"
```

Likewise, arithmetic operations between *EgadsData* instances are handled using the unit comprehension provided by *Quantities*, and behave . For example adding units of a similar type is permitted:

```
>>> a = egads.EgadsData(10, 'm')
>>> b = egads.EgadsData(5, 'km')
>>> a + b
['EgadsData', array(5010.0), 'm']
```

But, non-compatible types cannot be added. They can, however, be multiplied or divided:

```
>>> distance = egads.EgadsData(10, 'm')
>>> time = egads.EgadsData(1, 's')
>>> distance + time
ValueError: Unable to convert between units of "s" and "m"
>>> distance/time
['EgadsData', array(10), 'm/s']
```

## 3.3 Working with raw text files

EGADS provides the `egads.input.text_file_io.EgadsFile` class as a simple wrapper for interacting with generic text files. `EgadsFile` can read, write and display data from text files, but does not have any tools for automatically formatting input or output data.

### 3.3.1 Opening

To open a text file, simply create a `EgadsFile` instance with the parameters `filename` and `perms`:

```
>>> import egads
>>> f = egads.input.EgadsFile('/pathname/filename.nc', 'r')
```

**EgadsFile** (*filename* [, *perms*='r'] )

Open a text file.

#### Parameters

- **filename** (*string*) – path and filename of a text file
- **perms** (*string*) – permissions ; optional

**Return type** text file

Valid values for permissions are:

- `r` – Read: opens file for reading only. Default value if nothing is provided.
- `w` – Write: opens file for writing, and overwrites data in file.
- `a` – Append: opens file for appending data.
- `r+` – Read and write: opens file for both reading and writing.

### 3.3.2 File Manipulation

The following methods are available to control the current position in the file and display more information about the file.

**f.display\_file()**

Prints contents of the file out to a standard output.

**f.get\_position()**

Returns the current position in the file as an integer.

**f.seek** (*location* [, *from\_where*='b'] )

Seeks to a specified location in the text file.

#### Parameters

- **location** (*int*) – it is an integer specifying how far to seek
- **from\_where** (*string*) – it is an option to specify from where to seek, valid options for *from\_where* are `b` to seek from beginning of file, `c` to seek from current position in file and `e` to seek from the end of the file ; optional

**Return type** position in the text file

**f.reset()**

Resets the position to the beginning of the file.

### 3.3.3 Reading Data

Reading data is done using the `read(size)` method on a file that has been opened with `r` or `r+` permissions:

```
>>> import egads
>>> f = egads.input.EgadsFile()
>>> f.open('myfile.txt', 'r')
>>> single_char_value = f.read()
>>> multiple_chars = f.read(10)
```

If the `size` parameter is not specified, the `read()` function will input a single character from the open file. Providing an integer value  $n$  as the `size` parameter to `read(size)` will return  $n$  characters from the open file.

Data can be read line-by-line from text files using `read_line()`:

```
>>> line_in = f.read_line()
```

### 3.3.4 Writing Data

To write data to a file, use the `write(data)` method on a file that has been opened with `w`, `a` or `r+` permissions:

```
>>> import egads
>>> f = egads.input.EgadsFile()
>>> f.open('myfile.txt', 'a')
>>> data = 'Testing output data to a file.\n This text will appear on the 2nd line.
↪ '
>>> f.write(data)
```

### 3.3.5 Closing

To close a file, simply call the `close()` method:

```
>>> f.close()
```

### 3.3.6 Tutorial

Here is a basic ASCII file, created by EGADS:

```
# The current file has been created with EGADS
# Institution: My Institution
# Author(s): John Doe
time      sea level      corr sea level
1.0       5.0       1.0
2.0       2.0       3.0
3.0      -2.0      -1.0
4.0       0.5       2.5
5.0       4.0       6.0
```

This file has been created with the following commands:

- import EGADS module:

```
>>> import egads
```

- create two main variables, following the official EGADS convention:

```
>>> data1 = egads.EgadsData(value=[5.0,2.0,-2.0,0.5,4.0], units='mm', name=
↪ 'sea level', scale_factor=1., add_offset=0., _FillValue=-9999)
>>> data2 = egads.EgadsData(value=[1.0,3.0,-1.0,2.5,6.0], units='mm', name=
↪ 'corr sea level', scale_factor=1., add_offset=0., _FillValue=-9999)
```

- create an independant variable, still by following the official EGADS convention:

```
>>> time = egads.EgadsData(value=[1.0,2.0,3.0,4.0,5.0], units='seconds since_
↪ 19700101T00:00:00', name='time')
```

- create a new EgadsFile instance:

```
>>> f = egads.input.EgadsFile()
```

- use the following function to open a new file:

```
>>> f.open('main_raw_file.dat', 'w')
```

- prepare the headers if necessary:

```
>>> headers = '# The current file has been created with EGADS\n# Institution: \n↪My Institution\n# Author(s): John Doe\n'\n>>> headers += time.metadata["long_name"] + ' ' + data1.metadata["long_name"\n↪"] + ' ' + data2.metadata["long_name"] + '\n' + 'My institution')
```

- prepare an object to receive all data:

```
>>> data = ''\n>>> for i, _ in enumerate(time.value):\n    ... data += str(time.value[i]) + ' ' + str(data1.value[i]) + ' ' + \n↪str(data2.value[i]) + '\n'
```

- write the headers and data into the file

```
>>> f.write(headers)\n>>> f.write(data)
```

- and do not forget to close the file:

```
>>> f.close()
```

## 3.4 Working with CSV files

`egads.input.text_file_io.EgadsCsv` is designed to easily input or output data in CSV format. Data input using `EgadsCsv` is separated into a list of arrays, which each column a separate array in the list.

### 3.4.1 Opening

To open a csv file, simply create a `EgadsCsv` instance with the parameters `filename`, `perms`, `delimiter` and `quotechar`:

```
>>> import egads
>>> f = egads.input.EgadsCsv('/pathname/filename.nc', 'r', ',', '"')
```

**EgadsFile** (`filename`[, `perms`='r', `delimiter`=' ', `quotechar`='"'])

Open a text file.

#### Parameters

- **filename** (*string*) – path and filename of a text file
- **perms** (*string*) – permissions ; optional
- **delimiter** (*string*) – a one-character string used to separate fields ; optional
- **quotechar** (*string*) – a one-character string used to quote fields containing special characters ; optional

**Return type** csv file

Valid values for permissions are:

- `r` – Read: opens file for reading only. Default value if nothing is provided.
- `w` – Write: opens file for writing, and overwrites data in file.
- `a` – Append: opens file for appending data.
- `r+` – Read and write: opens file for both reading and writing.

### 3.4.2 File Manipulation

The following methods are available to control the current position in the file and display more information about the file.

`f.display_file()`

Prints contents of the file out to a standard output.

`f.get_position()`

Returns the current position in the file as an integer.

`f.seek(location[, from_where='b'])`

Seeks to a specified location in the text file.

#### Parameters

- **location** (*int*) – it is an integer specifying how far to seek
- **from\_where** (*string*) – it is an option to specify from where to seek, valid options for `from_where` are `b` to seek from beginning of file, `c` to seek from current position in file and `e` to seek from the end of the file ; optional

**Return type** position in the text file

`f.reset()`

Resets the position to the beginning of the file.

### 3.4.3 Reading Data

Reading data is done using the `read(lines, format)` method on a file that has been opened with `r` or `r+` permissions:

```
>>> import egads
>>> f = egads.input.EgadsCsv()
>>> f.open('mycsvfile.csv', 'r')
>>> single_line_as_list = f.read(1)
>>> all_lines_as_list = f.read()
```

`f.read([lines=None, format=None])`  
Returns a list of items read in from the CSV file.

#### Parameters

- **lines** (*int*) – if it is provided, the function will read in the specified number of lines, otherwise it will read the whole file ; optional
- **format** (*string*) – it is an optional list of characters used to decompose the elements read in from the CSV files to their proper types, options are ; optional

**Return type** list of items read in from the CSV file

Valid options for *format*:

- `i` – int
- `f` – float
- `l` – long
- `s` – string

Thus to read in the line:

FGBTM,20050105T143523,1.5,21,25

the command to input with proper formatting would look like this:

```
>>> data = f.read(1, ['s', 's', 'f', 'f'])
```

### 3.4.4 Writing Data

To write data to a file, use the `write(data)` method on a file that has been opened with `w`, `a` or `r+` permissions:

```
>>> import egads
>>> f = egads.input.EgadsCsv()
>>> f.open('mycsvfile.csv', 'a')
>>> titles = ['Aircraft ID', 'Timestamp', 'Value1', 'Value2', 'Value3']
>>> f.write(titles)
```

where the `titles` parameter is a list of strings. This list will be output to the CSV, with each strings separated by the delimiter specified when the file was opened (default is `,`).

To write multiple lines out to a file, `writerows(data)` is used:

```
>>> data = [['FGBTM', '20050105T143523', 1.5, 21, 25], ['FGBTM', '20050105T143524', 1.6,
↪ 20, 25.6]]
>>> f.writerows(data)
```

### 3.4.5 Closing

To close a file, simply call the `close()` method:

```
>>> f.close()
```

### 3.4.6 Tutorial

Here is a basic CSV file, created by EGADS:

```
time,sea level,corrected sea level
1.0,5.0,1.0
2.0,2.0,3.0
3.0,-2.0,-1.0
4.0,0.5,2.5
5.0,4.0,6.0
```

This file has been created with the following commands:

- import EGADS module:

```
>>> import egads
```

- create two main variables, following the official EGADS convention:

```
>>> data1 = egads.EgadsData(value=[5.0,2.0,-2.0,0.5,4.0], units='mm', name=
↳ 'sea level', scale_factor=1., add_offset=0., _FillValue=-9999)
>>> data2 = egads.EgadsData(value=[1.0,3.0,-1.0,2.5,6.0], units='mm', name=
↳ 'corr sea level', scale_factor=1., add_offset=0., _FillValue=-9999)
```

- create an independant variable, still by following the official EGADS convention:

```
>>> time = egads.EgadsData(value=[1.0,2.0,3.0,4.0,5.0], units='seconds since_
↳ 19700101T00:00:00', name='time')
```

- create a new EgadsFile instance:

```
>>> f = egads.input.EgadsCsv()
```

- use the following function to open a new file:

```
>>> f.open('main_csv_file.csv', 'w', ',', '"')
```

- prepare the headers if necessary:

```
>>> headers = ['time', 'sea level', 'corrected sea level']
```

- prepare an object to receive all data:

```
>>> data = [time.value, data1.value, data2.value]
```

- write the headers and data into the file

```
>>> f.write(headers)
>>> f.write(data)
```

- and do not forget to close the file:

```
>>> f.close()
```



## 3.5 Working with NetCDF files

EGADS provides two classes to work with NetCDF files. The simplest, `egads.input.netcdf_io.NetCdf`, allows simple read/write operations to NetCDF files. The other, `egads.input.netcdf_io.EgadsNetCdf`, is designed to interface with NetCDF files conforming to the EUFAR Standards & Protocols data and metadata regulations. This class directly reads or writes NetCDF data using instances of the `EgadsData` class.

### 3.5.1 Opening

To open a NetCDF file, simply create a `EgadsNetCdf` instance or a `NetCdf` instance with the parameters `filename` and `perms`:

```
>>> import egads
>>> f = egads.input.EgadsNetCdf('/pathname/filename.nc', 'r')
```

**EgadsNetCdf** (`filename` [, `perms`='r'])

Open a NetCDF file conforming the the EUFAR Standards & Protocols data and metadata regulations.

**Parameters**

- **filename** (*string*) – path and filename of a NetCDF file
- **perms** (*string*) – permissions ; optional

**Return type** NetCDF file.

Valid values for permissions are:

- `r` – Read: opens file for reading only. Default value if nothing is provided.
- `w` – Write: opens file for writing, and overwrites data in file.
- `a` – Append: opens file for appending data.
- `r+` – Same as `a`.

### 3.5.2 Getting info

`f.get_dimension_list` ([`varname=None`])

Returns a dictionary of all dimensions with their sizes. `varname` is optional and if provided, the function returns a dictionary of all dimensions and their sizes attached to `varname`.

**Parameters** **varname** (*string*) – name of a variable ; optional

**Return type** dictionary of dimensions

`f.get_attribute_list` ([`varname=None`])

Returns a list of all top-level attributes. `varname` is optional and if provided, the function returns a dictionary of all attributes attached to `varname`.

**Parameters** **varname** (*string*) – name of a variable ; optional

**Return type** dictionary of attributes

`f.get_variable_list` ()

Returns a list of all variables.

**Return type** list of variables

`f.get_filename` ()

Returns the filename for the currently opened file.

**Return type** filename

`f.get_perms` ()

Returns the current permissions on the file that is open.

Return type permissions

### 3.5.3 Reading data

To read data from a file, use the `read_variable()` function:

```
>>> data = f.read_variable(varname, input_range, read_as_float, replace_fill_value)
```

`f.read_variable(varname[, input_range=None, read_as_float=False, replace_fill_value=False])`

If using the `NetCdf` class, an array of values contained in `varname` will be returned. If using the `EgadsNetCdf` class, an instance of the `EgadsData` class will be returned containing the values and attributes of `varname`.

#### Parameters

- **varname** (*string*) – name of a variable in the NetCDF file
- **input\_range** (*list*) – list of min/max values ; optional
- **read\_as\_float** (*bool*) – if True, EGADS reads the data and convert them to float numbers, if False, the data type is the type of data in file ; optional
- **replace\_fill\_value** (*bool*) – if True, EGADS reads the data and replace `_FillValue` or `missing_value` (if one of the attributes exists) in data by NaN (`numpy.nan`) ; optional

Return type data, `EgadsData` or array

### 3.5.4 Writing data

The following describe how to add dimensions or attributes to a file.

`f.add_dim(name, size)`

Add a dimension to the NetCDF file.

#### Parameters

- **name** (*string*) – the name of the dimension
- **size** (*int*) – the size of the dimension

`f.add_attribute(attrname, value[, varname=None])`

Add an attribute to the NetCDF file. If `varname` is None, the attribute is a global attribute, and if not, the attribute is a variable attribute attached to `varname`.

#### Parameters

- **attrname** (*string*) – the name of the attribute
- **value** (*string|float|int*) – the value of the attribute
- **varname** (*string*) – the name of the variable to which to attach the attribute ; optional

Data can be output to variables using the `write_variable()` function as follows:

```
>>> f.write_variable(data, varname, dims, ftype, fillvalue)
```

`f.write_variable(data, varname[, dims=None, ftype='double', fillvalue=None])`

Write the values contained in `data` in the variable `varname` in a NetCDF file. If using `NetCdf`, values for `data` passed into `write_variable` must be scalar or array. Otherwise, if using `EgadsNetCdf`, an instance of `EgadsData` must be passed into `write_variable`. In this case, any attributes that are contained within the `EgadsData` instance are applied to the NetCDF variable as well. If an attribute with a name equal to `_FillValue` or `missing_value` is found, NaN in data will be automatically replaced by the missing value.

#### Parameters

- **data** (*EgadsData/array/vector/scalar*) – values to be stored in the NetCDF file
- **varname** (*string*) – the name of the variable in the NetCDF file
- **dims** (*tuple*) – a tuple of dimension names for data (not needed if the variable already exists) ; optional
- **ftype** (*string*) – the data type of the variable, the default value is *double*, other valid options are *float*, *int*, *short*, *char* and *byte* ; optional
- **fillvalue** (*float/int*) – if it is provided, it overrides the default NetCDF `_FillValue` ; optional, it doesn't exist if using *EgadsNetCdf*

### 3.5.5 Conversion from NetCDF to NASA Ames file format

The conversion is only possible on opened NetCDF files. If modifications have been made and haven't been saved, the conversion won't take into account those modifications. Actually, the only File Format Index supported by the conversion is 1001. Consequently, if more than one independent variables are present in the NetCDF file, the file won't be converted and the function will raise an exception. If the user needs to convert a complex file with variables depending on multiple independent variables, the conversion should be done manually by creating a *NasaAmes* instance and a *NasaAmes* dictionary, by populating the dictionary and by saving the file.

To convert a NetCDF file to *NasaAmes* file format, simply use:

```
f.convert_to_nasa_ames([na_file=None, float_format=None, delimiter=' ', no_header=False])
```

Convert the opened NetCDF file to *NasaAmes* file.

#### Parameters

- **na\_file** (*string*) – it is the name of the output file once it has been converted, by default the name of the NetCDF file will be used with the extension *.na* (*na\_file* is *None*); optional
- **float\_format** (*string*) – it is the formatting string used for formatting floats when writing to output file ; optional
- **delimiter** (*string*) – it is a character or a sequence of character to use between data items in the data file ; optional (by default ' ', 4 spaces)
- **no\_header** (*bool*) – if it is set to *True*, then only the data blocks are written to file ; optional

To convert a NetCDF file to *NasaAmes* CSV file format, simply use:

```
f.convert_to_csv([csv_file=None, float_format=None, no_header=False])
```

Convert the opened NetCDF file to *NasaAmes* CSV file.

#### Parameters

- **csv\_file** (*string*) – it is the name of the output file once it has been converted, by default the name of the NetCDF file will be used with the extension *.csv* (*csv\_file* is *None*); optional
- **float\_format** (*string*) – it is the formatting string used for formatting floats when writing to output file ; optional
- **no\_header** (*bool*) – if it is set to *True*, then only the data blocks are written to file ; optional

### 3.5.6 Other operations

```
f.get_attribute_value(attrname[, varname=None])
```

Return the value of the global attribute *attrname*, or the value of the variable attribute *attrname* if *varname* is not *None*.

#### Parameters

- **attrname** (*string*) – the name of the attribute
- **varname** (*string*) – the name of the variable to which the attribute is attached

**Return type** value of the attribute

**f.change\_variable\_name** (*varname*, *newname*)

Change a variable name in the currently opened NetCDF file..

**Parameters**

- **attrname** (*string*) – the actual name of the variable
- **varname** (*string*) – the new name of the variable

### 3.5.7 Closing

To close a file, simply use the `close()` method:

```
>>> f.close()
```

**Note:** The EGADS *NetCdf* and *EgadsNetCdf* use the official NetCDF I/O routines, therefore, as described in the NetCDF documentation, it is not possible to remove a variable or more, and to modify the values of a variable. As attributes, global and those linked to a variable, are more dynamic, it is possible to remove, rename, or replace them.

### 3.5.8 Tutorial

Here is a NetCDF file, created by EGADS, and viewed by the command `ncdump -h ....`:

```
=> ncdump -h main_netcdf_file.nc
netcdf main_netcdf_file {
  dimensions:
    time = 5 ;
  variables:
    double time(time) ;
      time:units = "seconds since 19700101T00:00:00" ;
      time:long_name = "time" ;
    double sea_level(time) ;
      sea_level:_FillValue = -9999. ;
      sea_level:category = "TEST" ;
      sea_level:scale_factor = 1. ;
      sea_level:add_offset = 0. ;
      sea_level:long_name = "sea level" ;
      sea_level:units = "mm" ;
    double corrected_sea_level(time) ;
      corrected_sea_level:_FillValue = -9999. ;
      corrected_sea_level:units = "mm" ;
      corrected_sea_level:add_offset = 0. ;
      corrected_sea_level:scale_factor = 1. ;
      corrected_sea_level:long_name = "corr sea level" ;

  // global attributes:
    :Conventions = "CF-1.0" ;
    :history = "the netcdf file has been created by EGADS" ;
    :comments = "no comments on the netcdf file" ;
    :institution = "My institution" ;
}
```

This file has been created with the following commands:

- import EGADS module:

```
>>> import egads
```

- create two main variables, following the official EGADS convention:

```
>>> data1 = egads.EgadsData(value=[5.0,2.0,-2.0,0.5,4.0], units='mm', name=
↳ 'sea_level', scale_factor=1., add_offset=0., _FillValue=-9999)
>>> data2 = egads.EgadsData(value=[1.0,3.0,-1.0,2.5,6.0], units='mm', name=
↳ 'corr sea_level', scale_factor=1., add_offset=0., _FillValue=-9999)
```

- create an independant variable, still by following the official EGADS convention:

```
>>> time = egads.EgadsData(value=[1.0,2.0,3.0,4.0,5.0], units='seconds since_
↳ 19700101T00:00:00', name='time')
```

- create a new EgadsNetCdf instance with a file name:

```
>>> f = egads.input.EgadsNetCdf('main_netcdf_file.nc', 'w')
```

- add the global attributes to the NetCDF file:

```
>>> f.add_attribute('Conventions', 'CF-1.0')
>>> f.add_attribute('history', 'the netcdf file has been created by EGADS')
>>> f.add_attribute('comments', 'no comments on the netcdf file')
>>> f.add_attribute('institution', 'My institution')
```

- add the dimension(s) of your variable(s), here it is time:

```
>>> f.add_dim('time', len(time))
```

- write the variable(s), it is a good practice to write at the first place the independant variable time:

```
>>> f.write_variable(time, 'time', ('time',), 'double')
>>> f.write_variable(data1, 'sea_level', ('time',), 'double')
>>> f.write_variable(data2, 'corrected_sea_level', ('time',), 'double')
```

- and do not forget to close the file:

```
>>> f.close()
```

## 3.6 Working with NASA Ames files

EGADS provides two classes to work with NASA Ames files. The simplest, `egads.input.nasa_ames_io.NasaAmes`, allows simple read/write operations. The other, `egads.input.nasa_ames_io.EgadsNasaAmes`, is designed to interface with NASA Ames files conforming to the EUFAR Standards & Protocols data and metadata regulations. This class directly reads or writes NASA Ames file using instances of the `EgadsData` class. Actually, only the FFI 1001 has been interfaced with EGADS.

### 3.6.1 Opening

To open a NASA Ames file, simply create a `EgadsNasaAmes` instance with the parameters `pathname` and `permissions`:

```
>>> import egads
>>> f = egads.input.EgadsNasaAmes('/pathname/filename.na', 'r')
```

**EgadsNasaAmes** (*pathname* [, *permissions*='r'])

Open a NASA Ames file conforming the the EUFAR Standards & Protocols data and metadata regulations.

#### Parameters

- **filename** (*string*) – path and filename of a NASA Ames file
- **perms** (*string*) – permissions ; optional

**Return type** NasaAmes file.

Valid values for permissions are:

- `r` – Read: opens file for reading only. Default value if nothing is provided.
- `w` – Write: opens file for writing, and overwrites data in file.
- `a` – Append: opens file for appending data.
- `r+` – Same as `a`.

Once a file has been opened, a dictionary of NASA/Ames format elements is loaded into memory. That dictionary will be used to overwrite the file or to save a new file.

### 3.6.2 Getting info

**f.get\_dimension\_list** ([*na\_dict*=None])

Returns a list of all variable dimensions.

**Parameters** **na\_dict** (*dict*) – if provided, the function get dimensions from the NasaAmes dictionary *na\_dict*, if not dimensions are from the opened file ; optional

**Return type** dictionary of dimensions

**f.get\_attribute\_list** ([*varname*=None, *vartype*='main', *na\_dict*=None])

Returns a dictionary of all top-level attributes.

#### Parameters

- **varname** (*string*) – name of a variable, if provided, the function returns a dictionary of all attributes attached to *varname* ; optional
- **vartype** (*string*) – if provided and *varname* is not None, the function will search in the variable type *vartype* by default ; optional
- **na\_dict** (*dict*) – if provided, it will return a list of all top-level attributes, or all *varname* attributes, from the NasaAmes dictionary *na\_dict* ; optional

**Return type** dictionary of attributes

**f.get\_attribute\_value** (*attrname* [, *varname*=None, *vartype*='main', *na\_dict*=None])

Returns the value of a top-level attribute named *attrname*.

**Parameters**

- **attrname** (*string*) – the name of the attribute
- **varname** (*string*) – name of a variable, if provided, the function returns the value of the attribute attached to *varname* ; optional
- **vartype** (*string*) – if provided and *varname* is not *None*, the function will search in the variable type *vartype* by default ; optional
- **na\_dict** (*dict*) – if provided, it will return the value of an attribute from the NasaAmes dictionary *na\_dict* ; optional

**Return type** value of attribute

**f.get\_variable\_list** (*[na\_dict=None]*)

Returns a list of all variables.

**Parameters** **na\_dict** (*dict*) – if provided, it will return the list of all variables from the NasaAmes dictionary *na\_dict* ; optional

**Return type** list of variables

**f.get\_filename** ()

Returns the filename for the currently opened file.

**Return type** filename

**f.get\_perms** ()

Returns the current permissions on the file that is open.

**Return type** permissions

### 3.6.3 Reading data

To read data from a file, use the `read_variable()` function:

```
>>> data = f.read_variable(varname, na_dict, read_as_float, replace_fill_value)
```

**f.read\_variable** (*varname*, *[na\_dict=None, read\_as\_float=False, replace\_fill\_value=False]*)

If using the *NasaAmes* class, an array of values contained in *varname* will be returned. If using the *EgadsNasaAmes* class, an instance of the *EgadsData* class will be returned containing the values and attributes of *varname*.

**Parameters**

- **varname** (*string*) – name of a variable in the NasaAmes file
- **na\_dict** (*dict*) – it will tell to EGADS in which Nasa Ames dictionary to read data, if *na\_dict* is *None*, data are read in the opened file ; optional
- **read\_as\_float** (*bool*) – if *True*, EGADS reads the data and convert them to float numbers, if *False*, the data type is the type of data in file ; optional
- **replace\_fill\_value** (*bool*) – if *True*, EGADS reads the data and replace `_FillValue` or `missing_value` (if one of the attributes exists) in data by `NaN` (`numpy.nan`) ; optional

**Return type** data, *EgadsData* or array

### 3.6.4 Writing data

To write data to the current file or to a new file, the user must save a dictionary of NasaAmes elements. Few functions are available to help him to prepare the dictionary:

**f.create\_na\_dict** ()

Create a new dictionary populated with standard NasaAmes keys

```
f.write_attribute_value(attrname, attrvalue[, na_dict=None, varname=None, vartype='main']
                        ])
```

Write or replace a specific attribute (from the official NasaAmes attribute list) in the currently opened dictionary.

#### Parameters

- **attrname** (*string*) – name of the attribute in the NasaAmes dictionary
- **attrvalue** (*string/float/integer/list/array*) – value of the attribute
- **na\_dict** (*dict*) – if provided the function will write the attribute in the NasaAmes dictionary *na\_dict* ; optional
- **varname** (*string*) – if provided, write or replace a specific attribute linked to the variable *var\_name* in the currently opened dictionary ; accepted attributes for a variable are 'name', 'units', '\_FillValue' and 'scale\_factor', other attributes will be refused and should be passed as 'special comments' ; optional
- **vartype** (*string*) – if provided and *varname* is not *None*, the function will search in the variable type *vartype* by default ; optional

```
f.write_variable(data[, varname=None, vartype='main', attrdict=None, na_dict=None ])
```

Write or replace a variable in the currently opened dictionary. If using the *NasaAmes* class, an array of values for *data* is asked. If using the *EgadsNasaAmes* class, an instance of the *EgadsData* class must be injected for *data*. If a *EgadsData* is passed into the *write\_variable* function, any attributes that are contained within the *EgadsData* instance are automatically populated in the NASA Ames dictionary as well, those which are not mandatory are stored in the 'SCOM' attribute. If an attribute with a name equal to *\_FillValue* or *missing\_value* is found, NaN in data will be automatically replaced by the missing value.

#### Parameters

- **data** (*EgadsData/array/vector/scalar*) – values to be stored in the NasaAmes file
- **varname** (*string*) – the name of the variable ; if data is an *EgadsData*, mandatory if 'standard\_name' or 'long\_name' is not an attribute of *data* ; absolutely mandatory if *data* is not an *EgadsData* ; optional
- **vartype** (*string*) – the type of *data*, 'independant' or 'main', only mandatory if *data* must be stored as an independant variable (dimension) ; optional
- **attrdict** (*dict*) – a dictionary containing mandatory attributes ('name', 'units', '\_FillValue' and 'scale\_factor'), only mandatory if *data* is not an *EgadsData* ; optional
- **na\_dict** (*dict*) – if provided, the function stores the variable in the NasaAmes dictionary *na\_dict*

### 3.6.5 Saving a file

Once a dictionary is ready, use the *save\_na\_file()* function to save the file:

```
>>> data = f.save_na_file(filename, na_dict, float_format, delimiter, no_header):
```

```
f.save_na_file([filename=None, na_dict=None, float_format=None, delimiter=' ',
               no_header=False])
```

Save the opened NasaAmes dictionary and file.

#### Parameters

- **filename** (*string*) – is the name of the new file, if not provided, the name of the opened NasaAmes file is used ; optional
- **na\_dict** (*dict*) – the name of the NasaAmes dictionary to be saved, if not provided, the opened dictionary will be used ; optional



- **float\_format** (*string*) – the format of the floating numbers in the file (by default, no round up) ; optional
- **delimiter** (*string*) – it is a character or a sequence of character to use between data items in the data file ; optional (by default ‘ ’, 4 spaces)
- **no\_header** (*bool*) – if it is set to `True`, then only the data blocks are written to file ; optional

### 3.6.6 Conversion from NASA/Ames file format to NetCDF

When a NASA/Ames file is opened, all metadata and data are read and stored in memory in a dedicated dictionary. The conversion will convert that dictionary to generate a NetCDF file. If modifications are made to the dictionary, the conversion will take into account those modifications. Actually, the only File Format Index supported by the conversion in the NASA Ames format is 1001. Consequently, if variables depend on multiple independant variables (e.g. data is function of time, longitude and latitude), the file won’t be converted and the function will raise an exception. If the user needs to convert a complex file with variables depending on multiple independant variables, the conversion should be done manually by creating a NetCDF instance and by populating the NetCDF files with NASA/Ames data and metadata.

To convert a NASA/Ames file, simply use:

```
f.convert_to_netcdf([nc_file=None, na_dict=None])
```

Convert the opened NasaAmes file to NetCDF file format.

#### Parameters

- **nc\_file** (*string*) – if provided, the function will use *nc\_file* for the path and name of the new\_file, if not, the function will take the name and path of the opened NasaAmes file and replace the extension by ‘.nc’ ; optional
- **na\_dict** (*dict*) – the name of the NasaAmes dictionary to be converted, if not provided, the opened dictionary will be used ; optional

### 3.6.7 Other operations

```
f.read_na_dict()
```

Returns a deep copy of the current opened file dictionary

**Return type** deep copy of a dictionary

```
egads.input.nasa_ames_io.na_format_information()
```

Returns a text explaining the structure of a NASA/Ames file to help the user to modify or to create his own dictionary

**Return type** string

### 3.6.8 Closing

To close a file, simply use the `close()` method:

```
>>> f.close()
```

### 3.6.9 Tutorial

Here is a NASA/Ames file:

```
23      1001
John Doe
An institution
tide gauge
ATESTPROJECT
1      1
```

(continues on next page)

(continued from previous page)

```

2017 1 30      2017 1 30
0.0
time (seconds since 19700101T00:00:00)
2
1      1
-9999      -9999
sea level (mm)
corr sea level (mm)
3
=====SPECIAL COMMENTS=====
this file has been created with egads
=====END=====
4
=====NORMAL COMMENTS=====
headers:
time      sea level      corrected sea level
=====END=====
1.00      5.00      1.00
2.00      2.00      3.00
3.00      -2.00      -1.00
4.00      0.50      2.50
5.00      4.00      6.00

```

This file has been created with the following commands:

- import EGADS module:

```
>>> import egads
```

- create two main variables, following the official EGADS convention:

```

>>> data1 = egads.EgadsData(value=[5.0,2.0,-2.0,0.5,4.0], units='mm', name=
↳ 'sea level', scale_factor=1, _FillValue=-9999)
>>> data2 = egads.EgadsData(value=[1.0,3.0,-1.0,2.5,6.0], units='mm', name=
↳ 'corr sea level', scale_factor=1, _FillValue=-9999)

```

- create an independant variable, still by following the official EGADS convention:

```

>>> time = egads.EgadsData(value=[1.0,2.0,3.0,4.0,5.0], units='seconds since_
↳ 19700101T00:00:00', name='time')

```

- create a new NASA/Ames empty instance:

```
>>> f = egads.input.NasaAmes()
```

- initialize a new NASA/Ames dictionary:

```
>>> na_dict = f.create_na_dict()
```

- prepare the normal and special comments if needed, in a list, one cell for each line, or only one string with lines separated by \n:

```

>>> scom = ['=====SPECIAL COMMENTS=====','this file has been created_
↳ with egads','=====END=====']
>>> ncom = ['=====NORMAL COMMENTS=====','headers:','time      sea level_
↳ corrected sea level','=====END=====']
or
>>> scom = '=====SPECIAL COMMENTS=====\\nthis file has been created_
↳ with egads\\n=====END=====\\n'
>>> ncom = '=====NORMAL COMMENTS=====\\nheaders:\\ntime      sea level _
↳ corrected sea level\\n=====END=====\\n'

```

- populate the main NASA/Ames attributes:

```
>>> f.write_attribute_value('ONAME', 'John Doe', na_dict = na_dict) # ONAME is_
↳the name of the author(s)
>>> f.write_attribute_value('ORG', 'An institution', na_dict = na_dict) # ORG_
↳is the name of the organization responsible for the data
>>> f.write_attribute_value('SNAME', 'tide gauge', na_dict = na_dict) # SNAME_
↳is the source of data (instrument, observation, platform, ...)
>>> f.write_attribute_value('MNAME', 'ATESTPROJECT', na_dict = na_dict) #_
↳MNAME is the name of the mission, campaign, programme, project dedicated to_
↳data
>>> f.write_attribute_value('DATE', [2017, 1, 30], na_dict = na_dict) # DATE_
↳is the date at which the data recorded in this file begin (YYYY MM DD)
>>> f.write_attribute_value('NIV', 1, na_dict = na_dict) # NIV is the number_
↳of independent variables
>>> f.write_attribute_value('NSCOML', 3, na_dict = na_dict) # NSCOML is the_
↳number of special comments lines or the number of elements in the SCOM list
>>> f.write_attribute_value('NNCOML', 4, na_dict = na_dict) # NNCOML is the_
↳number of special comments lines or the number of elements in the NCOM list
>>> f.write_attribute_value('SCOM', scom, na_dict = na_dict) # SCOM is the_
↳special comments attribute
>>> f.write_attribute_value('NCOM', ncom, na_dict = na_dict) # NCOM is the_
↳normal comments attribute
```

- write each variable in the dictionary:

```
>>> f.write_variable(time, 'time', vartype="independant", na_dict = na_dict)
>>> f.write_variable(data1, 'sea level', vartype="main", na_dict = na_dict)
>>> f.write_variable(data2, 'corrected sea level', vartype="main", na_dict =_
↳na_dict)
```

- and finally, save the dictionary to a NASA/Ames file:

```
>>> f.save_na_file('na_example_file.na', na_dict)
```

## 3.7 Working with algorithms

Algorithms in EGADS are stored in the `egads.algorithms` module, and separated into sub-modules by category (microphysics, thermodynamics, radiation, etc). Each algorithm follows a standard naming scheme, using the algorithm's purpose and source:

```
{CalculatedParameter}{Detail}{Source}
```

For example, an algorithm which calculates static temperature, which was provided by CNRM would be named:

```
TempStaticCnrm
```

### 3.7.1 Getting algorithm information

There are several methods to get information about each algorithm contained in EGADS. The EGADS Algorithm Handbook is available for easy reference outside of Python. In the handbook, each algorithm is described in detail, including a brief algorithm summary, descriptions of algorithm inputs and outputs, the formula used in the algorithm, algorithm source and links to additional references. The handbook also specifies the exact name of the algorithm as defined in EGADS. The handbook can be found on the EGADS website.

Within Python, usage information on each algorithm can be found using the `help()` command:

```
>>> help(egads.algorithms.thermodynamics.VelocityTasCnrm)

>>> Help on class VelocityTasCnrm in module egads.algorithms.thermodynamics.
    velocity_tas_cnrm:

class VelocityTasCnrm(egads.core.egads_core.EgadsAlgorithm)
|   FILE          velocity_tas_cnrm.py
|
|   VERSION       $Revision: 104 $
|
|   CATEGORY      Thermodynamics
|
|   PURPOSE       Calculate true airspeed
|
|   DESCRIPTION   Calculates true airspeed based on static temperature,
|                 static pressure and dynamic pressure using St Venant's
|                 formula.
|
|   INPUT         T_s          vector  K or C      static temperature
|                 P_s          vector  hPa         static pressure
|                 dP           vector  hPa         dynamic pressure
|                 cpa          coeff.  J K-1 kg-1   specific heat of air (dry
|                 air is 1004 J K-1 kg-1)
|                 Racpa       coeff.  ()          R_a/c_pa
|
|   OUTPUT        V_p          vector  m s-1       true airspeed
|
|   SOURCE        CNRM/GMEI/TRAMM
|
|   REFERENCES    "Mecanique des fluides", by S. Candel, Dunod.
|
|                 Bulletin NCAR/RAF Nr 23, Feb 87, by D. Lenschow and
|                 P. Spyers-Duran
|
|   ...
```

### 3.7.2 Calling algorithms

Algorithms in EGADS generally accept and return arguments of *EgadsData* type, unless otherwise noted. This has the advantages of constant typing between algorithms, and allows metadata to be passed along the whole

processing chain. Units on parameters being passed in are also checked for consistency, reducing errors in calculations, and rescaled if needed. However, algorithms will accept any normal data type, as well. They can also return non-*EgadsData* instances, if desired.

To call an algorithm, simply pass in the required arguments, in the order they are described in the algorithm help function. An algorithm call, using the `VelocityTasCnrm` in the previous section as an example, would therefore be the following:

```
>>> V_p = egads.algorithms.thermodynamics.VelocityTasCnrm().run(T_s, P_s, dP,
    cpa, Racpa)
```

where the arguments `T_s`, `P_s`, `dP`, etc are all assumed to be previously defined in the program scope. In this instance, the algorithm returns an *EgadsData* instance to `V_p`. To run the algorithm, but return a standard data type (scalar or array of doubles), set the `return_Egads` flag to `false`.

```
>>> V_p = egads.algorithms.thermodynamics.VelocityTasCnrm(return_Egads=False) .
    run(T_s, P_s, dP, cpa, Racpa)
```

---

**Note:** When injecting a variable in an `EgadsAlgorithm`, the format of the variable should follow closely the documentation of the algorithm. If the variable is a scalar, and the algorithm needs a vector, the scalar should be surrounded by brackets: `52.123 -> [52.123]`.

---

## 3.8 Scripting

The recommended method for using EGADS is to create script files, which are extremely useful for common or repetitive tasks. This can be done using a text editor of your choice. The example script belows shows the calculation of density for all NetCDF files in a directory.

```
#!/usr/bin/env python

# import egads package
import egads
# import thermodynamic module and rename to simplify usage
import egads.algorithms.thermodynamics as thermo

# get list of all NetCDF files in 'data' directory
filenames = egads.input.get_file_list('data/*.nc')
f = egads.input.EgadsNetCdf() # create EgadsNetCdf instance

for name in filenames:      # loop through files

    f.open(name, 'a')        # open NetCdf file with append permissions
    T_s = f.read_variable('T_t') # read in static temperature
    P_s = f.read_variable('P_s') # read in static pressure from file
    rho = thermo.DensityDryAirCnrm().run(P_s, T_s) # calculate density
    f.write_variable(rho, 'rho', ('Time',)) # output variable

    f.close()                # close file
```

### 3.8.1 Scripting Hints

When scripting in Python, there are several important differences from other programming languages to keep in mind. This section outlines a few of these differences.

#### Importance of white space

Python differs from C++ and Fortran in how loops or nested statements are signified. Whereas C++ uses brackets ('{' and '}') and FORTRAN uses `end` statements to signify the end of a nesting, Python uses white space. Thus, for statements to nest properly, they must be set at the proper depth. As long as the document is consistent, the number of spaces used doesn't matter, however, most conventions call for 4 spaces to be used per level. See below for examples:

#### FORTRAN:

```
X = 0
DO I = 1,10
  X = X + I
  PRINT I
END DO
PRINT X
```

#### Python:

```
x = 0
for i in range(1,10):
    x = x + i
    print i
print x
```

## 3.9 Using the GUI

Since September 2016, a Graphical User Interface is available at <https://github.com/eufarn7sp/egads-gui>. It gives the user the possibility to explore data, apply/create algorithms, display and plot data. Still in beta state, the user will have the possibility in the future to work on a batch of file. For now, EGADS GUI comes as a simple python script and need to be launch from the terminal, if EGADS is installed, and once in the EGADS GUI directory:

```
>>> python egads_gui.py
```

It will be available soon as a stand alone (imbedding a version of EGADS CORE or using an already installed EGADS package).

---

**Note:** As for EGADS, the Graphical User Interface is available from two branches: master and Lineage (<https://github.com/EUFAR/egads-gui/tree/Lineage>). The Lineage one is only compatible with Python 3 and the earlier versions of EGADS Lineage.

---

## ALGORITHM DEVELOPMENT

### 4.1 Introduction

The EGADS framework is designed to facilitate integration of third-party algorithms. This is accomplished through creation of Python modules containing the algorithm code, and corresponding LaTeX files which contain the algorithm methodology documentation. This section will explain the elements necessary to create these files, and how to incorporate them into the broader package.

### 4.2 Python module creation

To guide creation of Python modules containing algorithms in EGADS, an algorithm template has been included in the distribution. It can be found in `doc/source/example_files/algorithm_template.py` and is shown below:

```
__author__ = "mfreer, ohenry"
__date__ = "2016-12-14 15:04"
__version__ = "1.0"
__all__ = []

import egads.core.egads_core as egads_core
import egads.core.metadata as egads_metadata

# 1. Change class name to algorithm name (same as filename) but
#    following MixedCase conventions.

class AlgorithmTemplate(egads_core.EgadsAlgorithm):

# 2. Edit docstring to reflect algorithm description and input/output
#    parameters used

    """
    This file provides a template for creation of EGADS algorithms.

    FILE          algorithm_template.py

    VERSION       1.0

    CATEGORY      None

    PURPOSE       Template for EGADS algorithm files

    DESCRIPTION ...

    INPUT         inputs      var_type    units    description

    OUTPUT        outputs     var_type    units    description

    SOURCE        sources
```

(continues on next page)



(continued from previous page)

```

REFERENCES references

"""

def __init__(self, return_Egads=True):
    egads_core.EgadsAlgorithm.__init__(self, return_Egads)

    # 3. Complete output_metadata with metadata of the parameter(s) to be
    #     produced by this algorithm. In the case of multiple parameters,
    #     use the following formula:
    #         self.output_metadata = []
    #         self.output_metadata.append(egads_metadata.VariableMetadata(...))
    #         self.output_metadata.append(egads_metadata.VariableMetadata(...))
    #         ...

    self.output_metadata = egads_metadata.VariableMetadata({
        'units': '%',
        'long_name': 'template',
        'standard_name': '',
        'Category': ['']
    })

    # 3 cont. Complete metadata with parameters specific to algorithm,
    #     including a list of inputs, a corresponding list of units, and
    #     the list of outputs. InputTypes are linked to the different
    #     var_type written in the docstring

    self.metadata = egads_metadata.AlgorithmMetadata({
        'Inputs': ['input'],
        'InputUnits': ['unit'],
        'InputTypes': ['vector'],
        'InputDescription': ['A description for an input'],
        'Outputs': ['template'],
        'OutputUnits': [%],
        'OutputTypes': ['vector'],
        'OutputDescription': ['A description for an output'],
        'Purpose': 'Template for EGADS algorithm files',
        'Description': '...',
        'Category': 'None',
        'Source': 'sources',
        'Reference': 'references',
        'Processor': self.name,
        'ProcessorDate': __date__,
        'ProcessorVersion': __version__,
        'DateProcessed': self.now()
    }, self.output_metadata)

    # 4. Replace the 'inputs' parameter in the three instances below with the
    #     list of input parameters to be used in the algorithm.

    def run(self, inputs):

        return egads_core.EgadsAlgorithm.run(self, inputs)

    # 5. Implement algorithm in this section.

    def _algorithm(self, inputs):

        ## Do processing here:

```

(continues on next page)

(continued from previous page)

```
return result
```

The best practice before starting an algorithm is to copy this file and name it following the EGADS algorithm file naming conventions, which is all lowercase with words separated by underscores. As an example, the file name for an algorithm calculating the wet bulb temperature contributed by DLR would be called `temperature_wet_bulb_dlr.py`.

Within the file itself, there are one rule to respect and several elements in this template that will need to be modified before this can be usable as an EGADS algorithm.:

1. **Format** An algorithm file is composed of different elements: metadata, class name, algorithm docstring, ... It is critical to respect the format of each element of an algorithm file, in particular the first metadata and the docstring, in term of beginning white spaces, line length, ... Even if it is not mandatory for EGADS itself, it will facilitate the integration of those algorithms in the new Graphical User Interface.
2. **Class name** The class name is currently 'AlgorithmTemplate', but this must be changed to the actual name of the algorithm. The conventions here are the same name as the filename (see above), but using MixedCase. So, following the example above, the class name would be `TemperatureWetBulbDlr`
3. **Algorithm docstring** The docstring is everything following the three quote marks just after the class definition. This section describes several essential aspects of the algorithm for easy reference directly from Python. This part is critical for the understanding of the algorithm by different users.
4. **Algorithm and output metadata** In the `__init__` method of the module, two important parameters are defined. The first is the 'output\_metadata', which defines the metadata elements that will be assigned to the variable output by the algorithm. A few recommended elements are included, but a broader list of variable metadata parameters can be found in the NetCDF standards document on the EUFAR website (<http://www.eufar.net/documents/6140>, Annexe III). In the case that there are multiple parameters output by the algorithm, the output\_metadata parameter can be defined as a list `VariableMetadata` instances.

Next, the 'metadata' parameter defines metadata concerning the algorithm itself. These information include the names, types, descriptions and units of inputs; names, units, types and descriptions of outputs; name, description, purpose, category, source, reference, date and version of the algorithm; date processed; and a reference to the output parameters. Of these parameters, only the names, types, descriptions and units of the inputs, names and descriptions of the outputs and category, source, reference, description and purpose of the algorithm need to be altered. The other parameters (name, date and version of the processor, date processed) are populated automatically.

#### **self.output\_metadata:**

- units: units of the output.
- long\_name: the name describing the output.
- standard\_name: a short name for the output.
- Category: Name(s) of probe category - comma separated list (cf. EUFAR document <http://www.eufar.net/documents/6140> for an example of possible categories).

#### **self.metadata:**

- Inputs: representation of each input in the documentation and in the code (ex: `P_a` for altitude pressure).
- InputUnits: a list of all input units, one unit per input, "" for dimensionless input and 'None' for the input accepting every kind of units.
- InputTypes: the type of the input (array, vector, coeff, ...) linked to the `var_type` string in the algorithm template ; the string `_optional` can be added to inform that the input is optional (used in the EGADS GUI).
- InputDescription: short description of each input.
- Outputs: representation of each output (ex: `P_a` for altitude pressure).

- OutputUnits: units of each output (cf. self.output\_metadata['units']).
- OutputTypes: type of each output (ex: vector).
- OutputDescription: short description of each output.
- Purpose: the goal of the algorithm.
- Description: a description of the algorithm.
- Category: the category of the algorithm (ex: Transforms, Thermodynamis, ...).
- Source : the source of the algorithm (ex: CNRM).
- Reference : the reference of the algorithm (ex: Doe et al, My wonderful algorithm, Journal of Algorithms, 11, pp 21-22, 2017).
- Processor: self.name.
- ProcessorDate: \_\_date\_\_.
- ProcessorVersion: \_\_version\_\_.
- DateProcessed: self.now().

---

**Note:** For algorithms in which the output units depend on the input units (i.e. a purely mathematical transform, derivative, etc), there is a specific methodology to tell EGADS how to set the output units. To do this, set the appropriate `units` parameter of `output_metadata` to `inputn` where `n` is the number of the input parameter from which to get units (starting at 0). For algorithms in which the units of the input has no importance, the input units should set to `None`. For algorithms in which the input units are dimensionless (a factor, a quantity, a coefficient), the units on the input parameter should be set to `' '`.

---

---

**Note:** EGADS accepts different kind of input type: `coeff.` for coefficient, `vector`, `array`, `string`, ... When writing the docstring of an algorithm and the metadata `InputTypes`, the user should write the type carefully as it is interpreted by EGADS. If a type depends on another variable or multiple variables, for example the time, or geographic coordinates, the variable name should be written between brackets (ex: `array[lon,lat]`). If a variable is optional, the user should add `, optional` to the type in the docstring, and `_optional` to the type in the metadata `InputTypes`.

---

5. **Definition of parameters** In both the `run` and `_algorithm` methods, the local names intended for inputs need to be included. There are three locations where the same list must be added (marked in bold):

- `def run(self, inputs)`
- `return egads_core.EgadsAlgorithm.run(self, inputs)`
- `def _algorithm(self, inputs)`

6. **Implementation of algorithm** The algorithm itself gets written in the `_algorithm` method and uses variables passed in by the user. The variables which arrive here are simply scalar or arrays, and if the source is an instance of `EgadsData`, the variables will be converted to the units you specified in the `InputUnits` of the algorithm metadata.

7. **Integration of the algorithm in EGADS** Once the algorithm file is ready, the user has to move it in the appropriate directory in the `./egads/algorithms/user` directory. Once it has been done, the `__init__.py` file has to be modified to declare the new algorithm. The following line can be added to the `__init__.py` file: `from the_name_of_the_file import *`.

If the algorithm requires a new directory, the user has to create it in the `user` directory, move the file inside and create a `__init__.py` file to declare the new directory and the algorithm to EGADS. A template can be found in `./egads/algorithms/user/file_templates/init_template.py` and is shown below:

```

"""
EGADS new algorithms. See EGADS Algorithm Documentation for more info.
"""

__author__ = "ohenry"
__date__ = "$Date:: 2017-01-27 10:52#$"
__version__ = "$Revision:: 1      $"

import logging
try:
    from the_name_of_my_new_algorithm_file import *
    logging.info('egads [corrections] algorithms have been loaded')
except Exception:
    logging.error('an error occurred during the loading of a [corrections]_
↪algorithm')

```

## 4.3 Documentation creation

Within the EGADS structure, each algorithm has accompanying documentation in the EGADS Algorithm Handbook. These descriptions are contained in LaTeX files, organized in a structure similar to the toolbox itself, with one algorithm per file. These files can be found in the Documentation/EGADS Algorithm Handbook directory in the EGADS package downloaded from GitHub repository: <https://github.com/EUFAR/egads/tree/Lineage>.

A template is provided to guide creation of the documentation files. This can be found at Documentation/EGADS Algorithm Handbook/algorithms/algorithm\_template.tex. The template is divided into 8 sections, enclosed in curly braces. These sections are explained below:

- **Algorithm name** Simply the name of the Python file where the algorithm can be found.
- **Algorithm summary** This is a short description of what the algorithm is designed to calculate, and should contain any usage caveats, constraints or limitations.
- **Category** The name of the algorithm category (e.g. Thermodynamics, Microphysics, Radiation, Turbulence, etc).
- **Inputs** At the minimum, this section should contain a table containing the symbol, data type (vector or coefficient), full name and units of the input parameters. An example of the expected table layout is given in the template.
- **Outputs** This section describes the parameters output from the algorithm, using the same fields as the input table (symbol, data type, full name and units). An example of the expected table layout is given in the template.
- **Formula** The mathematical formula for the algorithm is given in this section, if possible, along with a description of the techniques employed by the algorithm.
- **Author** Any information about the algorithm author (e.g. name, institution, etc) should be given here.
- **References** The references section should contain citations to publications which describe the algorithm.

In addition to these sections, the `index` and `algdesc` fields at the top of the file need to be filled in. The value of the `index` field should be the same as the algorithm name. The `algdesc` field should be the full English name of the algorithm.

---

**Note:** Any “\_” character in plain text in LaTeX needs to be offset by a “\”. Thus if the algorithm name is `temp_static_cnrm`, in LaTeX, it should be input as `temp\_static\_cnrm`.

---

### 4.3.1 Example

An example algorithm is shown below with all fields completed.

```
%% $Date: 2012-02-17 18:01:08 +0100 (Fri, 17 Feb 2012) $
%% $Revision: 129 $
\index{temp\_static\_cnrm}
\algdesc{Static Temperature}
{ %%%% Algorithm name %%%%
temp\_static\_cnrm
}
{ %%%% Algorithm summary %%%%
Calculates static temperature of the air from total temperature.
This method applies to probe types such as the Rosemount.
}
{ %%%% Category %%%%
Thermodynamics
}
{ %%%% Inputs %%%%
$T_t$ & Vector & Measured total temperature [K] \\
${\Delta}P$ & Vector & Dynamic pressure [hPa] \\
$P_s$ & Vector & Static pressure [hPa] \\
$r_f$ & Coeff. & Probe recovery coefficient \\
$R_a/c_{pa}$ & Coeff. & Gas constant of air divided by specific heat of air
at constant pressure
}
{ %%%% Outputs %%%%
$T_s$ & Vector & Static temperature [K]
}
{ %%%% Formula %%%%
\begin{displaymath}
T_s = \frac{T_t}{1+r_f \left( \left( 1+\frac{\Delta P}{P_s} \right)^{R_a/c_{pa}} -1 \right)} \nonumber
\end{displaymath}
}
{ %%%% Author %%%%
CNRM/GMEI/TRAMM
}
{ %%%% References %%%%
}
```

## 5.1 Core Classes

```
class egads.core.egads_core.EgadsData (value, units="", variable_metadata=None,
                                         dtype='float64', **attrs)
```

Bases: quantities.quantity.Quantity

This class is designed using the EUFAR Standards & Protocols data and metadata recommendations. Its purpose is to store related data and metadata and allow them to be passed between functions and algorithms in a consistent manner.

Constructor Variables

### Parameters

- **value** – Scalar or array of values to initialize EgadsData object.
- **units** (*string*) – Optional - String representation of units to be used for current EgadsData instance, e.g. 'm/s', 'kg', 'g/cm^3', etc.
- **variable\_metadata** (*VariableMetadata*) – Optional - VariableMetadata dictionary object containing relevant metadata for the current EgadsData instance.
- **\*\*attrs** – Optional - Keyword/value pairs of additional metadata which will be added into the existing variable\_metadata object.

**copy** ()

Generate and return a copy of the current EgadsData instance.

**get\_units** ()

Return units used in current EgadsData instance.

**print\_description** ()

Generate and return a description of current EgadsData instance.

**print\_shape** ()

Prints shape of current EgadsData instance

**rescale** (*units*)

Return a copy of the variable rescaled to the provided units.

**Parameters** **units** (*string*) – String representation of desired units.

```
class egads.core.egads_core.EgadsAlgorithm (return_Egads=True)
```

Bases: object

EGADS algorithm base class. All egads algorithms should inherit this class.

The EgadsAlgorithm class provides base methods for algorithms in EGADS and initializes algorithm attributes.

Initializes EgadsAlgorithm instance with None values for all standard attributes.

Constructor Variables

**Parameters** **return\_Egads** (*bool*) – Optional - Flag used to configure which object type will be returned by the current EgadsAlgorithm. If `true` an `:class: EgadsData` instance with relevant metadata will be returned by the algorithm, otherwise an array or scalar will be returned.

**get\_info** ()

Print docstring of algorithm to standard output.

**now** ()

Calculate and return current date/time in ISO 8601 format.

**processor** ()

Indicate the algorithm used to produce the output variable

**run** (\*args)

Basic run method. This method should be called from EgadsAlgorithm children, passing along the correct inputs to the `_call_algorithm` method.

**Parameters** **\*args** – Parameters to pass into algorithm in the order specified in algorithm metadata.

**time\_stamp** ()

Calculate and set date processed for all output variables.

## 5.2 Metadata Classes

**class** `egads.core.metadata.Metadata` (*metadata\_dict={}*, *conventions=None*, *metadata\_list=None*)

Bases: `dict`

This is a generic class designed to provide basic metadata storage and handling capabilities.

Initialize Metadata instance with given metadata in dict form.

**Parameters** **metadata\_dict** (*dict*) – Dictionary object containing metadata names and values.

**add\_items** (*metadata\_dict*)

Method to add metadata items to current Metadata instance.

**Parameters** **metadata\_dict** – Dictionary object containing metadata names and values.

**compliance\_check** (*conventions=None*)

Checks for compliance with metadata conventions. If no specific conventions are provided, then compliance check will be based on metadata conventions listed in Conventions metadata field.

**Parameters** **conventions** (*string/list*) – Optional - Comma separated string or list of conventions to use for conventions check. Current conventions recognized are CF, RAF, IWGADTS, EUFAR, NASA Ames

**set\_conventions** (*conventions*)

Sets conventions to be used in current Metadata instance

**Parameters** **conventions** (*list*) – List of conventions used in current metadata instance.

**class** `egads.core.metadata.FileMetadata` (*metadata\_dict*, *filename*, *conventions\_keyword='Conventions'*, *conventions=[]*)

Bases: `egads.core.metadata.Metadata`

This class is designed to provide basic storage and handling capabilities for file metadata.

Initialize Metadata instance with given metadata in dict form. Tries to determine which conventions are used by the metadata. The user can optionally supply which conventions the metadata uses.

**Parameters**

- **metadata\_dict** (*dict*) – Dictionary object containing metadata names and values.

- **filename** (*string*) – Filename for origin of file metadata.
- **conventions\_keyword** (*string*) – Optional - Keyword contained in metadata dictionary used to detect which metadata conventions are used.
- **conventions** (*list*) – Optional - List of metadata conventions used in provided metadata dictionary.

**set\_filename** (*filename*)

Sets file object used for current FileMetadata instance.

**Parameters filename** (*string*) – Filename of provided metadata.

```
class egads.core.metadata.VariableMetadata (metadata_dict,          par-
                                          ent_metadata_obj=None,    conven-
                                          tions=None)
```

Bases: *egads.core.metadata.Metadata*

This class is designed to provide storage and handling capabilities for variable metadata.

Initialize VariableMetadata instance with given metadata in dict form. If VariableMetadata comes from a file, the file metadata object can be provided to auto-detect conventions. Otherwise, the user can specify which conventions are used in the variable metadata.

#### Parameters

- **metadata\_dict** (*dict*) – Dictionary object containing variable metadata names and values
- **parent\_metadata\_obj** (*Metadata*) – Metadata, optional Metadata object for the parent object of current variable (file, algorithm, etc). This field is optional.
- **conventions** (*list*) – Optional - List of metadata conventions used in provided metadata dictionary.

**compliance\_check** (*conventions=None*)

Checks for compliance with metadata conventions. If no specific conventions are provided, then compliance check will be based on metadata conventions listed in Conventions metadata field.

**Parameters conventions** (*string/list*) – Optional - Comma separated string or list of conventions to use for conventions check. Current conventions recognized are CF, RAF, IWGADTS, EUFAR, NASA Ames

**set\_parent** (*parent\_metadata\_obj*)

Sets parent object of VariableMetadata instance.

**Parameters parent\_metadata\_obj** (*Metadata*) – Optional - Metadata object for the parent object of the current variable (file, algorithm, etc)

```
class egads.core.metadata.AlgorithmMetadata (metadata_dict,
                                          child_variable_metadata=None)
```

Bases: *egads.core.metadata.Metadata*

This class is designed to provide storage and handling capabilities for EGADS algorithm metadata. Stores instances of VariableMetadata objects to use to populate algorithm variable outputs.

Initialize AlgorithmMetadata instance with given metadata in dict form and any child variable metadata.

#### Parameters

- **metadata\_dict** (*dict*) – Dictionary object containing variable metadata names and values
- **child\_variable\_metadata** (*list*) – Optional - List containing VariableMetadata

**assign\_children** (*child*)

Assigns children to current AlgorithmMetadata instance. Children are typically VariableMetadata instances. If VariableMetadata instance is used, this method also assigns current AlgorithmMetadata instance as parent in VariableMetadata child.



**Parameters** `child` (`VariableMetadata`) – Child metadata object to add to current instance children.

## 5.3 File Classes

**class** `egads.input.input_core.FileCore` (`filename=None`, `perms='r'`, `**kwargs`)

Bases: `object`

Abstract class which holds basic file access methods and attributes. Designed to be subclassed by NetCDF, NASA Ames and basic text file classes.

### Constructor Variables

#### Parameters

- **filename** (`string`) – Optional - Name of file to open.
- **perms** (`char`) – Optional - Permissions used to open file. Options are `w` for write (overwrites data in file), `a` and `r+` for append, and `r` for read. `r` is the default value

Initializes file instance.

#### Parameters

- **filename** (`string`) – Optional - Name of file to open.
- **perms** (`char`) – Optional - Permissions used to open file. Options are `w` for write (overwrites data in file), `a` and `r+` for append, and `r` for read. `r` is the default value

**close** ()

Close opened file.

**get\_filename** ()

If file is open, returns the filename.

**get\_perms** ()

Returns the current permissions on the file that is open. Returns `None` if no file is currently open. Options are `w` for write (overwrites data in file), `a` and `r+` for append, and `r` for read.

**open** (`filename`, `perms=None`)

Opens file given filename.

#### Parameters

- **filename** (`string`) – Name of file to open.
- **perms** (`char`) – Optional - Permissions used to open file. Options are `w` for write (overwrites data in file), `a` and `r+` for append, and `r` for read. `r` is the default value

`egads.input.input_core.get_file_list` (`path`)

Given path, returns a list of all files in that path. Wildcards are supported.

Example:

```
file_list = get_file_list('data/*.nc')
```

**class** `egads.input.nasa_ames_io.NasaAmes` (`filename=None`, `perms='r'`)

Bases: `egads.input.input_core.FileCore`

EGADS module for interfacing with NASA Ames files.

Initializes NASA Ames instance.

#### Parameters

- **filename** (`string`) – Optional - Name of NetCDF file to open.
- **perms** (`char`) – Optional - Permissions used to open file. Options are `w` for write (overwrites data), `a` and `r+` for append, and `r` for read. `r` is the default value.

**convert\_to\_netcdf** (*nc\_file=None, na\_dict=None*)

Convert a NASA/Ames dictionary to a NetCDF file.

**Parameters**

- **nc\_file** (*string*) – Optional - String name of the netcdf file to be written. If no filename is passed, the function will use the name of the actually opened NASA/Ames file.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary to be converted. If no dictionary is entered, the dictionary currently opened during the open file process will be converted.

**create\_na\_dict** ()

Create a typical NASA/Ames dictionary. It is intended to be saved in a new file. The user will have to populate the dictionary with other functions.

**get\_attribute\_list** (*varname=None, vartype='main', na\_dict=None*)

Returns a list of attributes found in current NASA Ames file either globally or attached to a given variable, depending on the type

**Parameters**

- **varname** (*string/int*) – Optional - Name or number of variable to get list of attributes from. If no variable name is provided, the function returns global attributes. If independent variable attribute list is read, sequential number is useless as FFI 1001 has only one independent variable.
- **vartype** (*string/*) – Optional - type of variable to get list of attributes from. If no variable type is provided with the variable name, the function returns an attribute of the main variable .
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which to get the attribute list. By default, na\_dict = None and the attribute list is retrieved from the currently opened NASA/Ames file . Only mandatory if creating a new file or creating a new dictionary.

**get\_attribute\_value** (*attrname, varname=None, vartype='main', na\_dict=None*)

Returns the value of an attribute found in current NASA Ames file either globally or attached to a given variable (only name, units, \_FillValue and scale\_factor), depending on the type

**Parameters**

- **attrname** (*string*) – String name of attribute to write in currently open file.
- **varname** (*string/int*) – Optional - Name or number of variable to get list of attributes from. If no variable name is provided, the function returns global attributes. If independent variable attribute is read, sequential number is useless as FFI 1001 has only one independent variable.
- **vartype** (*string*) – Optional - type of variable to get list of attributes from. If no variable type is provided with the variable name, the function returns an attribute of the main variable.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which to get the attribute value. By default, na\_dict = None and the attribute value is retrieved from the currently opened NASA/Ames file . Only mandatory if creating a new file or creating a new dictionary.

**get\_dimension\_list** (*na\_dict=None*)

Returns a dictionary of all dimensions linked to their variables in NASA Ames dictionary.

**Parameters** **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which to get the dimension list. By default, na\_dict = None and the dimension list is retrieved from the currently opened NASA/Ames file . Only mandatory if creating a new file or creating a new dictionary.

**get\_variable\_list** (*na\_dict=None*, *vartype='main'*)

Returns list of all variables in NASA Ames file.

#### Parameters

- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which to get the variable list. By default, *na\_dict = None* and the variable list is retrieved from the currently opened NASA/Ames file. Only mandatory if creating a new file or creating a new dictionary.
- **vartype** (*string*) – Optional - the type of data to read Options are *independant* for independant variables, *main* for main variables.

**read\_na\_dict** ()

Read the dictionary from currently open NASA Ames file. Method accessible by the user to read the dictionary in a custom object.

**read\_variable** (*varname*, *na\_dict=None*, *read\_as\_float=False*, *replace\_fill\_value=False*)

Read in variable from currently open NASA Ames file to :class: NumpyArray object.

#### Parameters

- **varname** (*string/int*) – String name or sequential number of variable to read in from currently open file. If independant variable is read, sequential number is useless as FFI 1001 has only one independant variable.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which the variable will be read. By default, *na\_dict = None* and the variable is read to the currently opened dictionary. Only mandatory if creating a new file or creating a new dictionary.
- **read\_as\_float** (*boolean*) – Optional - if True, EGADS reads the data and convert them to float numbers. If False, the data type is the type of data in file. *False* is the default value.
- **replace\_fill\_value** (*boolean*) – Optional - if True, EGADS reads the data and replaces missing\_value to NaN. *False* is the default value.

**save\_na\_file** (*filename=None*, *na\_dict=None*, *float\_format=None*, *delimiter=' '*, *no\_header=False*)

Save a NASA/Ames dictionary to a file. IMPORTANT: only FFI 1001 is supported.

#### Parameters

- **filename** (*string*) – Optional - String name of the file to be written.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary to be saved. If no dictionary is entered, the dictionary currently opened during the open file process will be saved.
- **float\_format** (*string*) – Optional - The format of float numbers to be saved. If no string is entered, values are not round up. Ex: *'%.4f'* to round up to 4 decimals.
- **delimiter** (*string*) – Optional - A character or multiple characters to separate data. By default *' '* (four spaces) is used
- **no\_header** (*boolean*) – Optional - If *no\_header* is True then suppress writing the header and only write the data section. Default - False.

**write\_attribute\_value** (*attrname*, *attrvalue*, *na\_dict=None*, *varname=None*, *vartype='main'*)

Write the value of an attribute in current NASA Ames file either globally or attached to a given variable (only name, units, *\_FillValue* and *scale\_factor*), depending on the type

#### Parameters

- **attrname** (*string*) – String name of attribute to write in currently open file.
- **attrvalue** (*string/int/float/list*) – Value of attribute to write in currently open file.

- **na\_dict** (*dict*) – Optional - dictionary in which the attribute will be added. By default, `na_dict = None` and the attribute value is added to the currently opened dictionary. Only mandatory if creating a new file or creating a new dictionary.
- **varname** (*string/int*) – Optional - Name or number of variable to get list of attributes from. If no variable name is provided, the function returns global attributes.
- **vartype** (*string*) – Optional - type of variable to get list of attributes from. If no variable type is provided with the variable name, the function returns an attribute of the main variable .

**write\_variable** (*data*, *varname=None*, *vartype='main'*, *attrdict=None*, *na\_dict=None*)

Write or update a variable in the NASA/Ames dictionary.

#### Parameters

- **data** (*list/NumpyArray*) – Data to be written in the NASA/Ames dictionary. data can be a list of value or an NumpyArray instance.
- **varname** (*string/int*) – The name or the sequential number of the variable to be written in the dictionary.
- **vartype** (*string*) – The type of data to read, by default `main`. Options are `independant` for independant variables, `main` for main variables. `main` is the default value.
- **attrdict** (*dict*) – Optional - Dictionary of variable attribute linked to the variable to be written in the dictionary. Mandatory only if data is not already present in the dictionary. Mandatory attributes for NasaAmes: `units`, `scale_factor`, `_FillValue` and `standard_name` if `varname` is `None`. Other variable attributes are written in the SCOM file attribute.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which the variable will be added. By default, `na_dict = None` and the variable is added to the currently opened dictionary. Only mandatory if creating a new file or creating a new dictionary.

**class** `egads.input.nasa_ames_io.EgadsNasaAmes` (*filename=None*, *perms='r'*)

Bases: `egads.input.nasa_ames_io.NasaAmes`

EGADS class for reading and writing to NasaAmes files following EUFAR conventions. Inherits from the general EGADS NasaAmes module.

Initializes EgadsNasaAmes instance.

#### Parameters

- **filename** (*string*) – Optional - Name of NasaAmes file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are `w` for write (overwrites data), `a` and `r+` for append, and `r` for read. `r` is the default value.

**convert\_to\_netcdf** (*nc\_file=None*, *na\_dict=None*)

Convert a NASA/Ames dictionary to a NetCDF file.

#### Parameters

- **nc\_file** (*string*) – Optional - String name of the netcdf file to be written. If no filename is passed, the function will use the name of the actually opened NASA/Ames file.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary to be converted. If no dictionary is entered, the dictionary currently opened during the open file process will be converted.

**read\_variable** (*varname*, *na\_dict=None*, *read\_as\_float=False*, *replace\_fill\_value=False*)

Read in variable from currently open NASA Ames file to :class: `EgadsData` object. Any additional variable metadata is additionally read in.

#### Parameters

- **varname** (*string/int*) – String name or sequential number of variable to read in from currently open file. If independant variable is read, sequential number is useless as FFI 1001 has only one independant variable.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which the variable will be read. By default, `na_dict = None` and the variable is read to the currently opened dictionary. Only mandatory if creating a new file or creating a new dictionary.
- **read\_as\_float** (*boolean*) – Optional - if True, EGADS reads the data and convert them to float numbers. If False, the data type is the type of data in file. *False* is the default value.
- **replace\_fill\_value** (*boolean*) – Optional - if True, EGADS reads the data and replaces missing\_value to NaN. *False* is the default value.

**write\_variable** (*data, varname=None, vartype='main', na\_dict=None*)

Write or update a variable in the NASA/Ames dictionary.

#### Parameters

- **data** (*EgadsData*) – Data to be written in the NASA/Ames dictionary. data has to be an *EgadsData* instance.
- **varname** (*string/int*) – The name or the sequential number of the variable to be written in the dictionary.
- **vartype** (*string*) – The type of data to read, by default *main*. Options are *independant* for independant variables, *main* for main variables. *main* is the default value.
- **na\_dict** (*dict*) – Optional - The NASA/Ames dictionary in which the variable will be added. By default, `na_dict = None` and the variable is added to the currently opened dictionary. Only mandatory if creating a new file or creating a new dictionary.

**class** `egads.input.netcdf_io.NetCdf` (*filename=None, perms='r', \*\*kwargs*)

Bases: `egads.input.input_core.FileCore`

EGADS class for reading and writing to generic NetCDF files.

This module is a sub-class of *FileCore* and adapts the Python NetCDF4 library to the EGADS file-access methods.

Initializes file instance.

#### Parameters

- **filename** (*string*) – Optional - Name of file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are *w* for write (overwrites data in file), *a* and *r+* for append, and *r* for read. *r* is the default value

**add\_attribute** (*attrname, value, varname=None*)

Adds attribute to currently open file. If *varname* is included, attribute is added to specified variable, otherwise it is added to global file attributes.

#### Parameters

- **attrname** (*string*) – Attribute name.
- **value** (*string/float/int*) – Value to assign to attribute name.
- **varname** (*string*) – Optional - If *varname* is provided, attribute name and value are added to specified variable in the NetCDF file.

**add\_dim** (*name, size*)

Adds dimension to currently open file.

#### Parameters

- **name** (*string*) – Name of dimension to add

- **size** (*integer*) – Integer size of dimension to add.

**change\_variable\_name** (*varname, newname*)

Change the variable name in currently opened NetCDF file.

#### Parameters

- **varname** (*string*) – Name of variable to rename.
- **newname** (*string*) – The new name.

**convert\_to\_csv** (*csv\_file=None, float\_format=None, no\_header=False*)

Converts currently open NetCDF file to CSV file using the NasaAmes class.

#### Parameters

- **csv\_file** (*string*) – Optional - Name of output CSV file. If none is provided, name of current NetCDF is used and suffix changed to .csv
- **float\_format** (*string*) – Optional - The format of float numbers to be saved. If no string is entered, values are not round up. Ex: ‘%.4f’ to round up to 4 decimals. Default - None
- **no\_header** (*bool*) – Optional - If set to true, then only the data blocks are written to file. Default - False.

**convert\_to\_nasa\_ames** (*na\_file=None, float\_format=None, delimiter=' ', no\_header=False*)

Convert currently open NetCDF file to one or more NASA Ames files. For now can only process NetCdf files to NASA/Ames FFI 1001 : only time as an independant variable.

#### Parameters

- **na\_file** (*string*) – Optional - Name of output NASA Ames file. If none is provided, name of current NetCDF file is used and suffix changed to .na
- **delimiter** (*string*) – Optional - The delimiter desired for use between data items in the data file. Default - Tab.
- **float\_format** (*string*) – Optional - The format of float numbers to be saved. If no string is entered, values are not round up. Ex: ‘%.4f’ to round up to 4 decimals. Default - None
- **delimiter** – Optional - The delimiter desired for use between data items in the data file. Default - ‘ ’ (four spaces).
- **no\_header** (*bool*) – Optional - If set to true, then only the data blocks are written to file. Default - False.

**delete\_attribute** (*attrname, varname=None*)

Deletes attribute to currently open file. If varname is included, attribute is removed from specified variable, otherwise it is removed from global file attributes.

#### Parameters

- **attrname** (*string*) – Attribute name.
- **varname** (*string*) – Optional - If varname is provided, attribute removed from specified variable in the NetCDF file.

**get\_attribute\_list** (*varname=None*)

Returns a dictionary of attributes and values found in current NetCDF file either globally, or attached to a given variable.

**Parameters** **varname** (*string*) – Optional - Name of variable to get list of attributes from. If no variable name is provided, the function returns top-level NetCDF attributes.

**get\_attribute\_value** (*attrname, varname=None*)

Returns value of an attribute given its name. If a variable name is provided, the attribute is returned from the variable specified, otherwise the global attribute is examined.

**Parameters**

- **attrname** (*string*) – Name of attribute to examine
- **varname** (*string*) – Optional - Name of variable attribute is attached to. If none specified, global attributes are examined.

**get\_dimension\_list** (*varname=None*)

Returns an ordered dictionary of dimensions and their sizes found in the current NetCDF file. If a variable name is provided, the dimension names and lengths associated with that variable are returned.

**Parameters** **varname** (*string*) – Optional - Name of variable to get list of associated dimensions for. If no variable name is provided, the function returns all dimensions in the NetCDF file.

**get\_perms** ()

Returns the current permissions on the file that is open. Returns None if no file is currently open. Options are *w* for write (overwrites data in file), *a* and *r+* for append, and *r* for read.

**get\_variable\_list** ()

Returns a list of variables found in the current NetCDF file.

**open** (*filename, perms=None*)

Opens NetCDF file given filename.

**Parameters**

- **filename** (*string*) – Name of NetCDF file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are *w* for write (overwrites data in file), *a* and *r+* for append, and *r* for read. *r* is the default value

**read\_variable** (*varname, input\_range=None, read\_as\_float=False, replace\_fill\_value=False*)

Reads a variable from currently opened NetCDF file.

**Parameters**

- **varname** (*string*) – Name of NetCDF variable to read in.
- **input\_range** (*vector*) – Optional - Range of values in each dimension to input.
- **read\_as\_float** (*boolean*) – Optional - if True, EGADS reads the data and convert them to float numbers. If False, the data type is the type of data in file.
- **replace\_fill\_value** (*boolean*) – Optional - if True, EGADS reads the data and replaces `_FillValue` (or `missing_value`) to `NaN`, if one of those attributes exists in the NetCDF file. `False` is the default value.

**write\_variable** (*data, varname, dims=None, ftype='double', fillvalue=None*)

Writes/creates variable in currently opened NetCDF file.

**Parameters**

- **data** (*array*) – Array of values to output to NetCDF file.
- **varname** (*string*) – Name of variable to create/write to.
- **dims** (*tuple*) – Optional - Name(s) of dimensions to assign to variable. If variable already exists in NetCDF file, this parameter is optional. For scalar variables, pass an empty tuple.
- **ftype** (*string*) – Optional - Data type of variable to write. Defaults to `double`. If variable exists, data type remains unchanged. Options for type are `double`, `float`, `int`, `short`, `char`, and `byte`
- **fillvalue** (*float*) – Optional - Overrides default NetCDF `_FillValue`, if provided.

**class** `egads.input.netcdf_io.EgadsNetCdf` (*filename=None, perms='r'*)

Bases: `egads.input.netcdf_io.NetCdf`

EGADS class for reading and writing to NetCDF files following EUFAR conventions. Inherits from the general EGADS NetCDF module.

Initializes NetCDF instance.

#### Parameters

- **filename** (*string*) – Optional - Name of NetCDF file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are `w` for write (overwrites data), `a` and `r+` for append, and `r` for read. `r` is the default value.

**convert\_to\_csv** (*csv\_file=None, float\_format=None, no\_header=False*)

Converts currently open NetCDF file to CSV file using Nappy API.

#### Parameters

- **csv\_file** (*string*) – Optional - Name of output CSV file. If none is provided, name of current NetCDF is used and suffix changed to `.csv`
- **float\_format** (*string*) – Optional - The format of float numbers to be saved. If no string is entered, values are not round up. Ex: `'%.4f'` to round up to 4 decimals. Default - None
- **no\_header** (*bool*) – Optional - If set to true, then only the data blocks are written to file. Default - False.

**convert\_to\_nasa\_ames** (*na\_file=None, float\_format=None, delimiter=' ', no\_header=False*)

Convert currently open EGADS NetCDF file to one or more NASA Ames files. For now can only process NetCdf files to NASA/Ames FFI 1001 : variables can only be dependant to one independant variable at a time.

#### Parameters

- **na\_file** (*string*) – Optional - Name of output NASA Ames file. If none is provided, name of current NetCDF file is used and suffix changed to `.na`
- **float\_format** (*string*) – Optional - The format of float numbers to be saved. If no string is entered, values are not round up. Ex: `'%.4f'` to round up to 4 decimals. Default - None
- **delimiter** (*string*) – Optional - The delimiter desired for use between data items in the data file. Default - `' '` (four spaces).
- **no\_header** (*bool*) – Optional - If set to true, then only the data blocks are written to file. Default - False.

**read\_variable** (*varname, input\_range=None, read\_as\_float=False, replace\_fill\_value=False*)

Reads in a variable from currently opened NetCDF file and maps the NetCDF attributies to an `EgadsData` instance.

#### Parameters

- **varname** (*string*) – Name of NetCDF variable to read in.
- **input\_range** (*vector*) – Optional - Range of values in each dimension to input. None is the default value.
- **read\_as\_float** (*boolean*) – Optional - if True, EGADS reads the data and convert them to float numbers. If False, the data type is the type of data in file. False is the default value.
- **replace\_fill\_value** (*boolean*) – Optional - if True, EGADS reads the data and replaces `_FillValue` (or `missing_value`) to NaN. False is the default value.

**write\_variable** (*data, varname=None, dims=None, ftype='double'*)

Writes/creates variable in currently opened NetCDF file.



### Parameters

- **data** (*EgadsData*) – Instance of EgadsData object to write out to file. All data and attributes will be written out to the file.
- **varname** (*string*) – Optional - Name of variable to create/write to. If no varname is provided, and if cdf\_name attribute in EgadsData object is defined, then the variable will be written to cdf\_name.
- **dims** (*tuple*) – Optional - Name(s) of dimensions to assign to variable. If variable already exists in NetCDF file, this parameter is optional. For scalar variables, pass an empty tuple.
- **ftype** (*string*) – Optional - Data type of variable to write. Defaults to double. If variable exists, data type remains unchanged. Options for type are double, float, int, short, char, and byte

**class** `egads.input.text_file_io.EgadsFile` (*filename=None, perms='r'*)

Bases: `egads.input.input_core.FileCore`

Generic class for interfacing with text files.

Initializes instance of EgadsFile object.

### Parameters

- **filename** (*string*) – Optional - Name of file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are w for write (overwrites data), a for append r+ for read and write, and r for read. r is the default value.

**close** ()

Close opened file.

**display\_file** ()

Prints contents of file out to standard output.

**get\_position** ()

Returns current position in file.

**read** (*size=None*)

Reads data in from file.

**Parameters** **size** (*int*) – Optional - Number of bytes to read in from file. If left empty, entire file will be read in.

**Returns** String data from text file.

**Return type** string

**read\_line** ()

Reads single line of data from file.

**reset** ()

Returns to beginning of file

**seek** (*location, from\_where='b'*)

Change current position in file.

### Parameters

- **location** (*integer*) – Position in file to seek to.
- **from\_where** (*char*) – Optional - Where to seek from. Valid options are b for beginning, c for current and e for end. Default is b.

**write** (*data*)

Writes data to a file. Data must be in the form of a string, with line ends signified by \n.

**Parameters** **data** (*string*) – Data to output to current file at current file position. Data must be a string, with `\n` signifying line end.

**class** `egads.input.text_file_io.EgadsCsv` (*filename=None, perms='r', delimiter=', ', quotechar=''*)

Bases: `egads.input.text_file_io.EgadsFile`

Class for reading data from CSV files.

Initializes instance of EgadsFile object.

#### Parameters

- **filename** (*string*) – Optional - Name of file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are `w` for write (overwrites data), `a` for append `r+` for read and write, and `r` for read. `r` is the default value.
- **delimiter** (*string*) – Optional - One-character string used to separate fields. Default is `','`.
- **quotechar** (*string*) – Optional - One-character string used to quote fields containing special characters. The default is `''`.

**display\_file** ()

Prints contents of file out to standard output.

**open** (*filename, perms, delimiter=None, quotechar=None*)

Opens file.

#### Parameters

- **filename** (*string*) – Name of file to open.
- **perms** (*char*) – Optional - Permissions used to open file. Options are `w` for write (overwrites data), `a` for append `r+` for read and write, and `r` for read. `r` is the default value.
- **delimiter** (*string*) – Optional - One-character string used to separate fields. Default is `','`.
- **quotechar** (*string*) – Optional - One-character string used to quote fields containing special characters. The default is `''`.

**read** (*lines=None, out\_format=None*)

Reads in and returns contents of csv file.

#### Parameters

- **lines** (*int*) – Optional - Number specifying the number of lines to read in. If left blank, the whole file will be read and returned.
- **out\_format** (*list*) – Optional - List type composed of one character strings used to decompose elements read in to their proper types. Options are `i` for int, `f` for float, `l` for long and `s` for string.

**Returns** List of arrays of values read in from file. If a format string is provided, the arrays are returned with the proper data type.

**Return type** list of arrays

**skip\_line** (*amount=1*)

Skips over line(s) in file.

**Parameters** **amount** (*int*) – Optional - Number of lines to skip over. Default value is 1.

**write** (*data*)

Writes single row out to file.

**Parameters** **data** (*list*) – Data to be output to file using specified delimiter.

**writerows** (*data*)

Writes data out to file.

**Parameters** **data** (*list*) – List of variables to output.

`egads.input.text_file_io.parse_string_array` (*data*, *data\_format*)

Converts elements in string list using format list to their proper types.

**Parameters**

- **data** (*numpy.ndarray*) – Input string array.
- **data\_format** (*list*) – List type composed of one character strings used to decompose elements read in to their proper types. Options are ‘i’ for int, ‘f’ for float, ‘l’ for long and ‘s’ for string.

**Returns** Array parsed into its proper types.

**Return type** `numpy.ndarray`

## PYTHON MODULE INDEX

### e

`egads.core.egads_core`, 35  
`egads.core.metadata`, 36  
`egads.input.input_core`, 38  
`egads.input.nasa_ames_io`, 38  
`egads.input.netcdf_io`, 42  
`egads.input.text_file_io`, 46

## INDEX

- add\_attribute() (egads.input.netcdf\_io.NetCdf method), 42
- add\_dim() (egads.input.netcdf\_io.NetCdf method), 42
- add\_items() (egads.core.metadata.Metadata method), 36
- AlgorithmMetadata (class in egads.core.metadata), 37
- assign\_children() (egads.core.metadata.AlgorithmMetadata method), 37
- change\_variable\_name() (egads.input.netcdf\_io.NetCdf method), 43
- close() (egads.input.input\_core.FileCore method), 38
- close() (egads.input.text\_file\_io.EgadsFile method), 46
- compliance\_check() (egads.core.metadata.Metadata method), 36
- compliance\_check() (egads.core.metadata.VariableMetadata method), 37
- convert\_to\_csv() (egads.input.netcdf\_io.EgadsNetCdf method), 45
- convert\_to\_csv() (egads.input.netcdf\_io.NetCdf method), 43
- convert\_to\_nasa\_ames() (egads.input.netcdf\_io.EgadsNetCdf method), 45
- convert\_to\_nasa\_ames() (egads.input.netcdf\_io.NetCdf method), 43
- convert\_to\_netcdf() (egads.input.nasa\_ames\_io.EgadsNasaAmes method), 41
- convert\_to\_netcdf() (egads.input.nasa\_ames\_io.NasaAmes method), 38
- copy() (egads.core.egads\_core.EgadsData method), 35
- create\_na\_dict() (egads.input.nasa\_ames\_io.NasaAmes method), 39
- delete\_attribute() (egads.input.netcdf\_io.NetCdf method), 43
- display\_file() (egads.input.text\_file\_io.EgadsCsv method), 47
- display\_file() (egads.input.text\_file\_io.EgadsFile method), 46
- egads.core.egads\_core (module), 35
- egads.core.metadata (module), 36
- egads.input.input\_core (module), 38
- egads.input.nasa\_ames\_io (module), 38
- egads.input.nasa\_ames\_io.na\_format\_information() (built-in function), 22
- egads.input.netcdf\_io (module), 42
- egads.input.text\_file\_io (module), 46
- EgadsAlgorithm (class in egads.core.egads\_core), 35
- EgadsCsv (class in egads.input.text\_file\_io), 47
- EgadsData (class in egads.core.egads\_core), 35
- EgadsFile (class in egads.input.text\_file\_io), 46
- EgadsFile() (built-in function), 8, 11
- EgadsNasaAmes (class in egads.input.nasa\_ames\_io), 41
- EgadsNasaAmes() (built-in function), 19
- EgadsNetCdf (class in egads.input.netcdf\_io), 44
- EgadsNetCdf() (built-in function), 14
- f.add\_attribute() (built-in function), 15
- f.add\_dim() (built-in function), 15
- f.change\_variable\_name() (built-in function), 17
- f.convert\_to\_csv() (built-in function), 16
- f.convert\_to\_nasa\_ames() (built-in function), 16
- f.convert\_to\_netcdf() (built-in function), 22
- f.create\_na\_dict() (built-in function), 20
- f.display\_file() (built-in function), 8, 11
- f.get\_attribute\_list() (built-in function), 14, 19
- f.get\_attribute\_value() (built-in function), 16, 19
- f.get\_dimension\_list() (built-in function), 14, 19
- f.get\_filename() (built-in function), 14, 20
- f.get\_permissions() (built-in function), 14, 20
- f.get\_position() (built-in function), 8, 11
- f.get\_variable\_list() (built-in function), 14, 20
- f.read() (built-in function), 12
- f.read\_na\_dict() (built-in function), 22
- f.read\_variable() (built-in function), 15, 20
- f.reset() (built-in function), 8, 11
- f.save\_na\_file() (built-in function), 21
- f.seek() (built-in function), 8, 11
- f.write\_attribute\_value() (built-in function), 20
- f.write\_variable() (built-in function), 15, 21
- FileCore (class in egads.input.input\_core), 38
- FileMetadata (class in egads.core.metadata), 36
- get\_attribute\_list() (egads.input.nasa\_ames\_io.NasaAmes method), 39
- get\_attribute\_list() (egads.input.netcdf\_io.NetCdf method), 43
- get\_attribute\_value() (egads.input.nasa\_ames\_io.NasaAmes method), 39

get\_attribute\_value() (egads.input.netcdf\_io.NetCdf method), 43  
 get\_dimension\_list() (egads.input.nasa\_ames\_io.NasaAmes method), 39  
 get\_dimension\_list() (egads.input.netcdf\_io.NetCdf method), 44  
 get\_file\_list() (in module egads.input.input\_core), 38  
 get\_filename() (egads.input.input\_core.FileCore method), 38  
 get\_info() (egads.core.egads\_core.EgadsAlgorithm method), 36  
 get\_perms() (egads.input.input\_core.FileCore method), 38  
 get\_perms() (egads.input.netcdf\_io.NetCdf method), 44  
 get\_position() (egads.input.text\_file\_io.EgadsFile method), 46  
 get\_units() (egads.core.egads\_core.EgadsData method), 35  
 get\_variable\_list() (egads.input.nasa\_ames\_io.NasaAmes method), 39  
 get\_variable\_list() (egads.input.netcdf\_io.NetCdf method), 44  
 Metadata (class in egads.core.metadata), 36  
 NasaAmes (class in egads.input.nasa\_ames\_io), 38  
 NetCdf (class in egads.input.netcdf\_io), 42  
 now() (egads.core.egads\_core.EgadsAlgorithm method), 36  
 open() (egads.input.input\_core.FileCore method), 38  
 open() (egads.input.netcdf\_io.NetCdf method), 44  
 open() (egads.input.text\_file\_io.EgadsCsv method), 47  
 parse\_string\_array() (in module egads.input.text\_file\_io), 48  
 print\_description() (egads.core.egads\_core.EgadsData method), 35  
 print\_shape() (egads.core.egads\_core.EgadsData method), 35  
 processor() (egads.core.egads\_core.EgadsAlgorithm method), 36  
 read() (egads.input.text\_file\_io.EgadsCsv method), 47  
 read() (egads.input.text\_file\_io.EgadsFile method), 46  
 read\_line() (egads.input.text\_file\_io.EgadsFile method), 46  
 read\_na\_dict() (egads.input.nasa\_ames\_io.NasaAmes method), 40  
 read\_variable() (egads.input.nasa\_ames\_io.EgadsNasaAmes method), 41  
 read\_variable() (egads.input.nasa\_ames\_io.NasaAmes method), 40  
 read\_variable() (egads.input.netcdf\_io.EgadsNetCdf method), 45  
 read\_variable() (egads.input.netcdf\_io.NetCdf method), 44  
 rescale() (egads.core.egads\_core.EgadsData method), 35  
 reset() (egads.input.text\_file\_io.EgadsFile method), 46  
 run() (egads.core.egads\_core.EgadsAlgorithm method), 36  
 save\_na\_file() (egads.input.nasa\_ames\_io.NasaAmes method), 40  
 seek() (egads.input.text\_file\_io.EgadsFile method), 46  
 set\_conventions() (egads.core.metadata.Metadata method), 36  
 set\_filename() (egads.core.metadata.FileMetadata method), 37  
 set\_parent() (egads.core.metadata.VariableMetadata method), 37  
 skip\_line() (egads.input.text\_file\_io.EgadsCsv method), 47  
 time\_stamp() (egads.core.egads\_core.EgadsAlgorithm method), 36  
 VariableMetadata (class in egads.core.metadata), 37  
 write() (egads.input.text\_file\_io.EgadsCsv method), 47  
 write() (egads.input.text\_file\_io.EgadsFile method), 46  
 write\_attribute\_value() (egads.input.nasa\_ames\_io.NasaAmes method), 40  
 write\_variable() (egads.input.nasa\_ames\_io.EgadsNasaAmes method), 42  
 write\_variable() (egads.input.nasa\_ames\_io.NasaAmes method), 41  
 write\_variable() (egads.input.netcdf\_io.EgadsNetCdf method), 45  
 write\_variable() (egads.input.netcdf\_io.NetCdf method), 44  
 writerows() (egads.input.text\_file\_io.EgadsCsv method), 47